

American Rifle Predator - American Rifle Predator .308Win

Ruger American Rifle Predator



The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3-5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: American Rifle Predator .308Win
- Manufacturer: RUGER
- Product no.: BRD113082
- Mfr. No.: 17903128
- Barrel Finish: Matte Black
- Barrel Length: 18"
- Caliber: .308 Winchester
- Capacity: 4-Round
- Color: Moss Green
- Length: 38"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Right
- Twist Rate: 1-10
- Weight: 6.23 lbs
- Delivery weight: 2.85kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 965mm
- UPC: 736676069743

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Ruger American Rifle Predator .308Win](#)
- [English: Ruger American Rifle Predator Safety Instruction Guide](#)

Sicherheitshinweise für die Ruger American Rifle Predator .308Win

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf der Ruger American Rifle Predator .308Win. Diese Anleitung bietet wichtige Informationen zur sicheren Verwendung und Handhabung Ihres Gewehrs. Bitte lesen Sie alle Sicherheitsrichtlinien sorgfältig durch, um ein sicheres und verantwortungsvolles Schießen zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Verwende immer Gehör und Augenschutz, wenn du mit dem Gewehr schießt.
- Halte das Gewehr immer in einem sicheren Zustand, bis du bereit bist, zu schießen. Dies bedeutet, dass die Waffe entladen sein sollte, bis du sie tatsächlich benutzen möchtest.
- Richte das Gewehr niemals auf etwas, was du nicht treffen möchtest. Behalte immer die Mündung in eine sichere Richtung.
- Halte deinen Finger außerhalb des Abzugsbügels, bis du bereit bist, den Abzug zu betätigen.
- Überprüfe das Gewehr vor jedem Gebrauch auf Anzeichen von Beschädigungen oder Abnutzung.
- Bewahre Munition und Gewehr getrennt und sicher auf, um unbefugten Zugriff zu verhindern.

Besondere Sicherheitsvorkehrungen für die Verwendung

- Lese und verstehe die Bedienungsanleitung, bevor du das Gewehr benutzt.
- Verwende nur die vom Hersteller empfohlene Munition (.308 Winchester).
- Achte auf die Umgebung, in der du schießt, um sicherzustellen, dass keine Personen oder Tiere in der Nähe sind.
- Schieße niemals unter dem Einfluss von Alkohol oder Drogen.
- Lasse das Gewehr niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern oder ungeschulten Personen.
- Bei Fehlzündungen oder anderen Problemen, lasse das Gewehr für mindestens 30 Sekunden in der sicheren Position, bevor du es überprüfst.

Anweisungen für Installation und Verwendung

- **Installation:**
 - Stelle sicher, dass das Gewehr entladen ist, bevor du Zubehör wie Optiken oder Schalldämpfer installierst.
 - Befolge die spezifischen Anweisungen des Herstellers für die Montage von Zubehör.
- **Verwendung:**
 - Lade das Gewehr nur in einem sicheren Bereich.
 - Stelle sicher, dass das Magazin richtig eingesetzt ist, bevor du das Gewehr lädst.
 - Überprüfe die Mündung des Gewehrs regelmäßig auf Verstopfungen.
 - Nach dem Schießen, reinige das Gewehr gemäß den Anweisungen in der Bedienungsanleitung.

Entsorgungsanweisungen

- Entsorge leere Munition und andere Abfälle gemäß den örtlichen Gesetzen und Vorschriften.
- Bringe das Gewehr nicht einfach in den Müll. Wende dich an eine autorisierte Sammelstelle oder einen Fachhändler für die ordnungsgemäße Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zur Sicherheit deines Gewehrs wende dich bitte an den Hersteller oder einen autorisierten Händler. Stelle sicher, dass du alle relevanten Informationen bereithältst, um eine schnelle und effektive Unterstützung zu erhalten.

Wichtige Hinweise

- Melde unsichere Produkte oder Vorfälle den zuständigen Behörden.
- Überprüfe regelmäßig die Rückrufupdates auf der EU Safety GatePlattform.

Vielen Dank, dass du dir die Zeit genommen hast, diese Sicherheitsrichtlinien zu lesen. Ein sicheres Schießen ist ein verantwortungsvolles Schießen!

Ruger American Rifle Predator Safety Instruction Guide

Introduction

Thank you for choosing the Ruger American Rifle Predator .308Win. This safety instruction guide is designed to help you understand how to safely use and maintain your rifle. Please read this guide carefully before use to ensure your safety and the safety of others.

General Safety Guidelines

- Always treat the rifle as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the rifle for any signs of damage or wear.
- Use only the recommended ammunition for your rifle.
- Follow all local laws and regulations regarding firearm usage and ownership.

Specific Safety Precautions for Use

- **Ergonomic Handling:** Ensure a proper grip on the lightweight synthetic stock. The textured grip areas provide superior control.
- **Trigger Adjustment:** Familiarize yourself with the Ruger Marksman Adjustable Trigger, which is externally adjustable between 1.4 and 2.3 kg (3-5 lbs). Always ensure the adjustment key is securely stored in the bolt when not in use.
- **Muzzle Safety:** Always ensure the muzzle is pointed in a safe direction when loading or unloading the rifle.
- **Shooting Conditions:** Be mindful of the environment and conditions when hunting or shooting. Adjust your approach based on weather and terrain.
- **Hunting Precautions:** When hunting, make sure to identify your target clearly before shooting. Use appropriate safety gear and follow hunting regulations.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure that any accessories are compatible with the Ruger American Rifle Predator.
- Follow the manufacturer's instructions for installation of scopes, bipods, or other accessories.

2. Loading the Rifle:

- Open the bolt and ensure the chamber is clear.
- Insert the magazine into the rifle, ensuring it clicks into place.
- Load the appropriate .308 Winchester cartridges into the magazine.
- Close the bolt gently to chamber a round.

3. Shooting the Rifle:

- Position yourself in a stable shooting stance.
- Aim at your target, ensuring a clear line of sight.
- Take a deep breath, relax, and gently squeeze the trigger to fire.

- After firing, keep the rifle pointed downrange until you are ready to unload.

4. Unloading the Rifle:

- Open the bolt to eject any chambered round.
- Remove the magazine from the rifle.
- Visually and physically inspect the chamber to ensure it is clear.

Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations regarding firearms.
- If you need to dispose of ammunition, contact local law enforcement or a licensed firearms dealer for guidance on safe disposal methods.
- Ensure that any parts or accessories are disposed of safely to prevent unauthorized use.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of your Ruger American Rifle Predator, please refer to the official Ruger website or contact your local Ruger dealer for assistance.

By following these guidelines, you can ensure a safe and enjoyable experience with your Ruger American Rifle Predator. Always prioritize safety and responsible firearm ownership.