

Magazine Follower Button for Ruger Pistols, 10 Pack

Magazine Follower Button for Ruger Pistols, 10 Pack



Have a sluggish MKII, MKIII, MK IV, or 22/45 Ruger magazine? Chances are the spring is fine but the actual culprit is the metal on metal contact of the magazine button.

Not only does this make magazines hard to load but it can also cause feeding problems by allowing the round to hang up before the bolt closes. If your magazine has a gritty and rough feeling when loading, we suggest using our Magazine Follower Button for incredibly smooth operation. Our button is knurled for easy gripping but more importantly, it eliminates the metal on metal contact providing easy loading and trouble free feeding.

Attributes

- Name: Magazine Follower Button for Ruger Pistols, 10 Pack
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231085
- Mfr. No.: VC3FB-10
- Make: Ruger
- Model: MKII, MKIII, MK IV
- Delivery weight: 0.2kg
- UPC: 810162014421

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Magazinknopf für RugerPistolen, 10erPack](#)
- [English: Magazine Follower Button for Ruger Pistols Safety Instruction Guide](#)

Sicherheitshinweise für den Magazinknopf für RugerPistolen, 10erPack

Einführung

Vielen Dank, dass Sie sich für den Magazinknopf für RugerPistolen entschieden haben. Dieses Produkt wurde entwickelt, um Ihnen eine reibungslose Nutzung Ihrer RugerMagazine zu ermöglichen. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Überprüfen Sie das Produkt regelmäßig auf Beschädigungen oder Abnutzung.
- Befolgen Sie alle Anweisungen zur Installation und Nutzung.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Besondere Sicherheitsvorkehrungen für die Nutzung

- Stellen Sie sicher, dass Ihre RugerPistole vollständig entladen ist, bevor Sie den Magazinknopf installieren oder entfernen.
- Verwenden Sie den Magazinknopf nicht, wenn Sie Anzeichen von Beschädigung oder Fehlfunktion feststellen.
- Achten Sie darauf, dass der Magazinknopf korrekt installiert ist, um Verletzungen oder Funktionsstörungen zu vermeiden.
- Verwenden Sie keine übermäßige Kraft beim Laden des Magazins, um Verletzungen zu vermeiden.

Anweisungen zur Installation und Nutzung

1. Installation des Magazinknopfes

- Stellen Sie sicher, dass die Pistole entladen ist.
- Entfernen Sie den alten Magazinknopf, indem Sie ihn vorsichtig abziehen oder die entsprechende Schraube lösen.
- Setzen Sie den neuen Magazinknopf auf die vorgesehene Stelle und drücken Sie ihn fest, bis er sicher sitzt.
- Überprüfen Sie, ob der Knopf korrekt sitzt und sich leicht bedienen lässt.

2. Nutzung des Magazinknopfes

- Laden Sie das Magazin, indem Sie die Patronen vorsichtig in die vorgesehenen Fächer einlegen.
- Verwenden Sie den gerändelten Knopf, um das Magazin zu laden, und achten Sie darauf, dass kein MetallaufMetallkontakt entsteht.
- Überprüfen Sie nach dem Laden, ob das Magazin ordnungsgemäß funktioniert und keine Blockaden aufweist.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektroschrott oder Kunststoffabfälle.
- Stellen Sie sicher, dass der Magazinknopf nicht in die Hände von Kindern gelangt, während Sie ihn entsorgen.

Kontaktinformationen für weitere Unterstützung

Für weitere Unterstützung oder Fragen zu diesem Produkt wenden Sie sich bitte an den Hersteller oder an den zuständigen Händler. Achten Sie darauf, dass Sie alle relevanten Informationen zu Ihrem Produkt bereithalten, wenn Sie Hilfe benötigen.

Bitte beachten Sie, dass die Sicherheit und Zufriedenheit unserer Kunden für uns von größter Bedeutung sind. Wir empfehlen Ihnen, regelmäßig auf Rückrufinformationen über die EU Safety GatePlattform zu überprüfen, um über mögliche Sicherheitsrisiken informiert zu bleiben.

Magazine Follower Button for Ruger Pistols

Safety Instruction Guide

Introduction

Thank you for choosing the Magazine Follower Button for Ruger Pistols. This product is designed to enhance the performance of your Ruger magazines by reducing metal-on-metal contact, leading to smoother operation and improved feeding. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- **Product Safety:** This product is designed for safe use with Ruger MKII, MKIII, MK IV, and 22/45 pistols. Always follow the manufacturer's guidelines for safe handling and usage.
- **Potential Hazards:** Improper installation or use may lead to feeding issues or damage to your firearm. Always ensure proper fit and functionality before use.
- **Vulnerable Groups:** This product is not intended for use by individuals under the age of 18. Keep out of reach of children.
- **Online Shopping Safety:** If purchased online, ensure the retailer complies with EU safety standards. Verify that the product is genuine and has not been altered.
- **Reporting Unsafe Products:** If you encounter any issues with this product, report them to the relevant authorities. Regularly check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Inspection:** Before installation, inspect the Magazine Follower Button for any visible damage or defects.
- **Compatibility:** Confirm that this product is compatible with your specific Ruger model (MKII, MKIII, MK IV, or 22/45).
- **Proper Handling:** Handle the product with care to avoid injury. Use appropriate tools for installation.
- **Loading Procedure:** When loading, ensure that the magazine is securely in place and that the follower button is correctly positioned.
- **Avoid Force:** Do not force the magazine button into the magazine. If it does not fit easily, check for obstructions or compatibility issues.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools, such as a small screwdriver, if required.

2. Installation:

- Remove the magazine from the firearm.
- Disassemble the magazine according to the manufacturer's instructions. This may involve removing a base plate or other components.
- Carefully remove the old follower button, if applicable.
- Insert the new Magazine Follower Button into the magazine, ensuring it fits securely.
- Reassemble the magazine, ensuring all components are correctly aligned and secured.

3. Usage:

- Load ammunition into the magazine as per the manufacturer's guidelines.

- Ensure that the magazine is inserted correctly into the firearm before attempting to fire.
- Test the magazine for smooth operation before use in a live setting.

4. **PostInstallation Check:**

- After installation, perform a function check to ensure the magazine operates smoothly.
- If any issues arise, consult a qualified gunsmith or contact customer support for assistance.

Disposal Instructions

- **Environmental Considerations:** Dispose of any packaging materials responsibly. Follow local regulations for the disposal of plastic and metal components.
- **Product Disposal:** If the Magazine Follower Button is no longer usable, dispose of it in accordance with local waste management regulations. Do not dispose of it in regular household waste if it can be recycled or requires special disposal.

Contact Information for Further Support

For any inquiries or further assistance regarding the Magazine Follower Button for Ruger Pistols, please refer to the manufacturer's website or customer service resources. Ensure to have your product details on hand for a more efficient support experience.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities. Enjoy your enhanced shooting experience with the Magazine Follower Button for Ruger Pistols!