

Summit Rifle, 22 LR, with Brown Lightweight Thumbhole Stock

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,



Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR, with Brown Lightweight Thumbhole Stock
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231156
- Mfr. No.: VCB-LR-B-LTH
- Barrel Finish: Carbon
- Caliber: .22lr
- Color: Brown
- Hand: Right
- Make: Ruger
- Material: Anodized Aluminum
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 2.8kg
- UPC: 810162017347

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Volquartsen Summit Repetierbüchse](#)
- [English: Summit Rifle, 22 LR Safety Instruction Guide](#)

Sicherheitshinweise für die Volquartsen Summit Repetierbüchse

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Volquartsen Summit Repetierbüchse! Diese Anleitung bietet Ihnen wichtige Sicherheitsinformationen, um die sichere Nutzung Ihres Gewehrs zu gewährleisten. Bitte lesen Sie alle Anweisungen sorgfältig durch, bevor Sie das Produkt verwenden.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Gewehr immer als geladen betrachtet wird, bis Sie sicher sind, dass es entladen ist.
- Halten Sie den Lauf immer in eine sichere Richtung, fern von Menschen und Tieren.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck, d.h. für Wettkampfschießen und Niederwildjagd.
- Bewahren Sie das Gewehr in einem sicheren, verschlossenen Bereich auf, wenn es nicht in Gebrauch ist.
- Überprüfen Sie regelmäßig, ob das Gewehr ordnungsgemäß funktioniert und keine sichtbaren Schäden aufweist.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die empfohlenen Munitionstypen (.22lr) für die Volquartsen Summit Repetierbüchse.
- Achten Sie darauf, dass die Mündungsgewinde (1/228) für Zubehörteile, wie Schalldämpfer, geeignet sind.
- Stellen Sie sicher, dass der Twist Rate (116) für Ihre verwendete Munition geeignet ist.
- Verwenden Sie das Gewehr nicht, wenn Sie unter dem Einfluss von Alkohol oder Drogen stehen.
- Halten Sie Kinder und unbefugte Personen jederzeit von dem Gewehr fern.

Anweisungen zur Installation und Nutzung

- Stellen Sie sicher, dass Sie alle Teile des Gewehrs vor der ersten Nutzung überprüfen.
- Um das Gewehr zu laden:
 1. Stellen Sie sicher, dass der Abzug nicht gedrückt wird.
 2. Führen Sie die Munition in das Magazin ein.
 3. Setzen Sie das Magazin in das Gewehr ein, bis es einrastet.
- Um das Gewehr zu entladen:
 1. Stellen Sie sicher, dass der Abzug nicht gedrückt wird.
 2. Entfernen Sie das Magazin.
 3. Ziehen Sie den Verschluss zurück, um sicherzustellen, dass sich keine Munition im Lauf befindet.
- Nach der Benutzung reinigen Sie das Gewehr gemäß den Herstelleranweisungen.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munitionreste gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Geben Sie das Gewehr nicht in den normalen Müll. Wenden Sie sich an eine autorisierte Entsorgungsstelle oder einen Fachmann für die sichere Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Anliegen zu Ihrer Volquartsen Summit Repetierbüchse wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler. Achten Sie darauf, dass alle Produkte über einen EUbasierten Kontakt

verfügen, um Sicherheitsanfragen zu beantworten.

Schlussfolgerung

Die Sicherheit hat bei der Nutzung der Volquartsen Summit Repetierbüchse oberste Priorität. Indem Sie diese Sicherheitsrichtlinien befolgen, tragen Sie dazu bei, eine sichere Umgebung für sich selbst und andere zu gewährleisten. Überprüfen Sie regelmäßig die Sicherheitsupdates und Rückrufinformationen auf der EU Safety Gate Plattform.

Summit Rifle, 22 LR Safety Instruction Guide

Introduction

Thank you for choosing the Summit Rifle, 22 LR, with Brown Lightweight Thumbhole Stock. This guide provides essential safety instructions to ensure the safe and responsible use of your rifle. Please read and follow all instructions carefully to maximize safety and enjoyment.

General Safety Guidelines

- Always treat the rifle as if it is loaded, even when you believe it is not.
- Keep the rifle pointed in a safe direction at all times.
- Only load the rifle when you are ready to shoot and ensure the muzzle is pointed downrange.
- Keep your finger off the trigger until you are ready to fire.
- Be aware of your target and what is beyond it.
- Store the rifle unloaded and locked in a secure location, out of reach of children and unauthorized users.
- Use appropriate safety gear, including eye and ear protection, when shooting.
- Regularly inspect the rifle for any signs of wear or damage. Do not use the rifle if it is damaged.
- Familiarize yourself with the rifle's operation before use.

Specific Safety Precautions for Use

- Ensure that only .22 LR ammunition is used with this rifle. Using incorrect ammunition can lead to malfunctions or serious injury.
- Do not attempt to modify or alter the rifle in any way.
- Avoid shooting in adverse weather conditions, such as strong winds or rain, which may affect your control and accuracy.
- Always ensure the area is clear of people and animals before firing.
- If you experience a misfire, keep the rifle pointed downrange for at least 30 seconds before attempting to unload it.
- Be cautious of the rifle's muzzle threads and ensure they are not obstructed.

Instructions for Installation and Usage

1. Unboxing the Rifle

- Carefully remove the rifle from the packaging.
- Check that all components are included and undamaged.

2. Loading the Rifle

- Ensure the rifle is pointed in a safe direction.
- Open the bolt to verify the chamber is clear.
- Insert a 10round magazine into the magazine well.
- Pull the bolt back to chamber a round.

3. Firing the Rifle

- Stand in a stable shooting position with feet shoulderwidth apart.
- Align your sights with the target.
- Gradually squeeze the trigger while maintaining your aim.

4. Unloading the Rifle

- After firing, open the bolt and remove the magazine.
- Visually inspect the chamber to ensure it is empty before handling the rifle further.

5. Cleaning and Maintenance

- Clean the rifle regularly to ensure optimal performance.
- Use a cleaning kit designed for .22 LR rifles and follow the manufacturer's instructions.

Disposal Instructions

- Dispose of any used ammunition and packaging in accordance with local regulations.
- If the rifle is no longer functional or is to be disposed of, contact a local gunsmith or authorized dealer for safe disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Summit Rifle, please consult the manufacturer's website or contact your local authorized dealer. It is essential to have a reliable source for information and support regarding the safe use of your rifle.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Summit Rifle, 22 LR. Always prioritize safety and responsibility when handling firearms. Thank you for your commitment to safe shooting practices.