

Summit Rifle, 22 LR Magpul Stock - Summit Rifle, 22 LR, Gray Magpul Stock

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,



Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR, Gray Magpul Stock
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231158
- Mfr. No.: VCB-LR-G
- Action Type: Bolt Action
- Barrel Finish: Carbon
- Caliber: .22lr
- Color: Gray
- Length Of Pull: 12.5" - 14.5"
- Make: Ruger
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 2.7kg
- UPC: 810162017613

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Volquartsen Summit Repetierbüchse](#)
- [English: Summit Rifle Safety Instruction Guide](#)

Sicherheitshinweise für die Volquartsen Summit Repetierbüchse

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Volquartsen Summit Repetierbüchse! Diese Anleitung bietet wichtige Informationen zu Sicherheit, Nutzung und Entsorgung des Produkts. Bitte lesen Sie diese Hinweise sorgfältig durch, um sicherzustellen, dass Sie Ihr Gewehr sicher und verantwortungsbewusst verwenden.

Allgemeine Sicherheitsrichtlinien

- Überprüfen Sie vor der Benutzung das Gewehr auf sichtbare Schäden oder Mängel.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck, d.h. zum Schießen mit .22 LR Munition.
- Halten Sie den Abzug immer in der sicheren Position, bis Sie bereit sind zu schießen.
- Lagern Sie das Gewehr sicher und außerhalb der Reichweite von Kindern und unbefugten Personen.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Achten Sie auf Ihre Umgebung und stellen Sie sicher, dass sich keine Personen oder Tiere im Schussbereich befinden.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Vermeiden Sie es, das Gewehr zu laden, während Sie sich bewegen oder das Ziel wechseln.
- Prüfen Sie immer, ob das Gewehr entladen ist, bevor Sie es reinigen oder warten.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, während es geladen ist.
- Verwenden Sie das Gewehr nicht unter dem Einfluss von Alkohol oder Drogen.

Anweisungen für Installation und Nutzung

- **Installation der PicatinnySchiene:** Stellen Sie sicher, dass das Gewehr entladen ist. Befestigen Sie die PicatinnySchiene gemäß den Anweisungen im Benutzerhandbuch sicher am Gewehr.
- **Laden des Gewehrs:** Überprüfen Sie, ob der Sicherheitsmechanismus aktiviert ist. Laden Sie das Magazin mit bis zu 10 Patronen .22 LR. Setzen Sie das Magazin vorsichtig in das Gewehr ein, bis es einrastet.
- **Abfeuern:** Stellen Sie sicher, dass das Ziel klar und sicher ist. Nehmen Sie eine stabile Schießposition ein. Betätigen Sie den Abzug vorsichtig, um das Gewehr abzufeuern.
- **Reinigung:** Reinigen Sie das Gewehr nach jedem Gebrauch, um die Leistung zu erhalten. Verwenden Sie geeignete Reinigungsmittel und werkzeuge, die für .22 LR Gewehre empfohlen werden.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Lagern Sie nicht mehr benötigte oder defekte Teile sicher, bis Sie sie gemäß den gesetzlichen Anforderungen entsorgen können.
- Überprüfen Sie die örtlichen Vorschriften zur Entsorgung von Waffen und Munition, um sicherzustellen, dass Sie alle gesetzlichen Anforderungen erfüllen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zur Sicherheit Ihres Produkts wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler.

Bitte beachten Sie, dass die Sicherheit an erster Stelle steht. Es liegt in Ihrer Verantwortung, die

Sicherheitshinweise zu befolgen und Ihr Gewehr verantwortungsbewusst zu verwenden. Bei Unsicherheiten oder Fragen zögern Sie nicht, professionelle Hilfe in Anspruch zu nehmen.

Summit Rifle Safety Instruction Guide

Introduction

Congratulations on your purchase of the Summit Rifle, 22 LR with a Magpul Stock. This guide provides essential safety instructions to ensure the safe use and handling of your rifle. Please read this manual carefully before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your rifle for any signs of wear or damage.
- Use only the recommended ammunition for your rifle.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when shooting.
- Ensure that the rifle is fully assembled and in good working condition before use.
- Use the safety mechanism when the rifle is not in use or when transporting it.
- Avoid using the rifle in wet or damp conditions to prevent rust and corrosion.
- Do not modify the rifle in any way that may compromise its safety or performance.
- Be cautious of your surroundings to avoid accidental injuries to yourself or others while shooting.

Instructions for Installation and Usage

Installation Instructions

1. Unpacking the Rifle:

- Carefully remove the rifle from the packaging.
- Check for any visible damage or missing components.
- Ensure all parts are included as per the product specifications.

2. Attaching the Stock:

- Align the stock with the receiver.
- Secure it using the provided screws, ensuring a tight fit.

3. Installing Accessories:

- If adding accessories, ensure they are compatible with the rifle.
- Follow the manufacturer's instructions for installation.

Usage Instructions

1. Loading the Rifle:

- Ensure the rifle is pointed in a safe direction.
- Open the bolt and insert the magazine into the magazine well until it clicks into place.
- Pull the bolt back and release it to chamber a round.

2. Firing the Rifle:

- Aim at your target, ensuring a clear line of sight.
- Place your finger on the trigger only when you are ready to shoot.
- Squeeze the trigger gently to fire.

3. Clearing the Rifle:

- After firing, keep the rifle pointed in a safe direction.
- Open the bolt to eject any remaining cartridges.
- Visually and physically check the chamber to ensure it is empty.

Disposal Instructions

When disposing of the rifle, please follow these guidelines:

- Do not dispose of the rifle in regular household waste.
- Contact your local authorities or a licensed firearms dealer for proper disposal methods.
- Ensure that all ammunition is removed and disposed of safely.

Contact Information for Further Support

For any questions or concerns regarding the Summit Rifle, please refer to the manufacturer's customer service resources. Ensure to have your product details ready for assistance.

Conclusion

Safety is paramount when handling firearms. By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your Summit Rifle. Always prioritize safety and responsible usage.