

EV30 Rucksack - Ash Green

Vorn hunting backpacks are used and praised by hunters around the world. With the weapon completely protected in the backpack, you can concentrate fully on the hunt.



The quick release system allows you to quickly and reliably grab the gun when you go to the ready.

The focus on details combined with high quality materials ensure that a Vorn backpack will sit comfortably on your back for many years!

The VORN EV30 with a volume of 30 liters is the smallest hunting backpack in the EV series. You have plenty of room for hunting equipment while enjoying the benefits of a compact and stylish hunting backpack.

- Patented QRR system for quick and reliable access to the hunting rifle.
- EV: outer and inner frame for optimal stability and carrying capacity.
- Spacious and adjustable gun compartment.
- Comfortable shoulder straps with VORN pin lock system for height adjustment.
- Strong hip belt with MOLLE attachment points.
- Compatible with hydration system (up to three liters).
- Side opening to entire main compartment
- Lid compartment with key hook
- Easy access padded front compartment
- Mesh pockets inside and outside
- Multiple handles, compression straps and attachment points
- Weapon cover for protection during transport
- Volume: 30 liters
- Weight: 2,45 kg

Additional information

- Fiber reinforced polymer frame
- Stainless steel trigger system
- Durable V-Tex, noiseless and water-resistant 3-layer fabric
- Water-repellent PU-coated YKK™ zippers, size #8
- Duraflex™ push-in closures
- High quality straps

Attributes

- Name: VORN EV30 Rucksack - Ash Green
- Manufacturer: VORN
- Product no.: BRD513083
- Mfr. No.: 0103
- Color: Ash Green
- Weight: 2,45 kg
- Delivery weight: 3kg
- EAN: 7090033551030

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den VORN EV30 Rucksack](#)
- [English: VORN EV30 Rucksack Safety Instructions](#)

Sicherheitshinweise für den VORN EV30 Rucksack

Einführung

Herzlichen Glückwunsch zum Kauf des VORN EV30 Rucksacks! Dieser Rucksack wurde speziell für Jäger entwickelt und bietet Ihnen eine sichere und komfortable Möglichkeit, Ihre Ausrüstung zu transportieren. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie den Rucksack sicher und effektiv nutzen.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass der Rucksack vor der ersten Benutzung auf sichtbare Schäden oder Mängel überprüft wird.
- Vermeiden Sie es, den Rucksack über seine maximale Tragfähigkeit hinaus zu beladen.
- Tragen Sie den Rucksack immer so, dass er sicher auf Ihrem Rücken sitzt und nicht verrutschen kann.
- Verwenden Sie den Rucksack nur für den vorgesehenen Zweck (Transport von Jagdausrüstung).
- Halten Sie den Rucksack von offenen Flammen und extremen Temperaturen fern.
- Achten Sie darauf, dass der Rucksack trocken bleibt, um die Materialien und die Ausrüstung zu schützen.
- Bei der Verwendung des Schnellauslösesystems sollten Sie sicherstellen, dass sich keine anderen Personen in der Nähe befinden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Überprüfen Sie vor jeder Verwendung, ob das QRRSystem (Quick Release Retention) ordnungsgemäß funktioniert.
- Achten Sie darauf, dass alle Gurte und Verschlüsse fest und sicher sind, bevor Sie den Rucksack anlegen.
- Verwenden Sie den gepolsterten Fach für die Waffe, um Verletzungen zu vermeiden.
- Tragen Sie den Rucksack nicht über längere Zeiträume, wenn er überladen ist.
- Vermeiden Sie plötzliche Bewegungen, wenn Sie den Rucksack tragen, um ein Ungleichgewicht zu verhindern.
- Wenn Sie den Rucksack ablegen, stellen Sie sicher, dass er auf einer stabilen Oberfläche steht.

Anweisungen für Installation und Nutzung

• Anlegen des Rucksacks:

1. Öffnen Sie alle Gurte und Sicherungen.
2. Legen Sie den Rucksack auf den Boden und stellen Sie sicher, dass alle Fächer leer sind.
3. Heben Sie den Rucksack an und ziehen Sie die Schultergurte über Ihre Schultern.
4. Passen Sie die Schultergurte mit dem VORNPIN LockSystem an Ihre Körpergröße an.
5. Sichern Sie den Hüftgurt und stellen Sie sicher, dass er fest sitzt.

• Verwendung des Waffensystems:

1. Öffnen Sie das Waffenfach und legen Sie Ihre Waffe vorsichtig hinein.
2. Stellen Sie sicher, dass die Waffe sicher im Fach sitzt und nicht herausfallen kann.
3. Verwenden Sie das Schnellauslösesystem, um schnell auf die Waffe zugreifen zu können, wenn nötig.

• Reinigung des Rucksacks:

1. Reinigen Sie den Rucksack regelmäßig mit einem feuchten Tuch, um Schmutz und Staub zu entfernen.
2. Vermeiden Sie aggressive Reinigungsmittel, die die Materialien beschädigen könnten.

3. Lassen Sie den Rucksack an der Luft trocknen, wenn er nass ist.

Entsorgungsanweisungen

- Der Rucksack sollte am Ende seiner Lebensdauer umweltgerecht entsorgt werden.
- Überprüfen Sie lokale Vorschriften zur Entsorgung von Textilprodukten und Kunststoffen.
- Wenn möglich, geben Sie den Rucksack an eine Recyclingstelle oder eine Wohltätigkeitsorganisation weiter, die ihn wiederverwenden kann.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zur Sicherheit und Nutzung des VORN EV30 Rucksacks wenden Sie sich bitte an den Hersteller oder den Einzelhändler, bei dem Sie das Produkt erworben haben.

VORN EV30 Rucksack Safety Instructions

Introduction

Thank you for choosing the VORN EV30 Rucksack in Ash Green. This product is designed for hunters who value both functionality and style. To ensure safe usage and longevity of your rucksack, please read and follow these safety instructions carefully.

General Safety Guidelines

- **Product Safety:** The VORN EV30 Rucksack is designed to be safe for use during hunting activities. Ensure you are familiar with all components before use.
- **Enhanced Recalls:** In the unlikely event of a product recall, you will be notified through standardized recall notices. Please follow the instructions provided in such cases.
- **Online Shopping:** If purchased online, ensure that the seller complies with EU safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Always supervise minors when using or handling the rucksack.
- **EU Contact Point:** For any safety inquiries, please refer to the contact information provided by the retailer or manufacturer.
- **Rapid Alerts:** Stay informed about product safety by checking the EU's Safety Gate platform for any updates regarding your product.

Specific Safety Precautions for Use

- **Check for Damage:** Before each use, inspect the rucksack for any signs of damage, such as tears or broken zippers. Do not use if damaged.
- **Load Capacity:** Do not exceed the rucksack's volume of 30 liters and weight capacity of 2.45 kg to avoid strain and ensure safe handling.
- **Weapon Safety:** Always ensure that your weapon is secured within the designated gun compartment and that it is unloaded when not in use.
- **Hydration System:** If using a hydration system, ensure it is properly installed and does not leak.
- **Weather Conditions:** Be aware of weather conditions. Avoid exposing the rucksack to extreme weather unless it is designed for such conditions.
- **Proper Use of Straps:** Adjust the shoulder straps and hip belt to fit securely and comfortably. Ensure all straps are fastened properly before moving.

Instructions for Installation and Usage

- **Adjusting the Rucksack:**
 - Place the rucksack on a flat surface.
 - Adjust the shoulder straps using the VORN pin lock system to fit your height and comfort.
 - Secure the hip belt around your waist and tighten for stability.
- **Loading the Rucksack:**
 - Open the main compartment and place your hunting equipment inside.
 - Use the spacious gun compartment to securely store your weapon.
 - Ensure that all items are properly packed and do not exceed the rucksack's capacity.
- **Accessing Your Weapon:**
 - Use the patented QRR system to quickly access your weapon when needed.
 - Practice using this system in a safe environment before heading out on a hunt.

- **Using the Padded Front Compartment:**

- Store items that require quick access in the padded front compartment.
- Ensure that this compartment is zipped securely after use.

- **Utilizing Additional Features:**

- Use the mesh pockets inside and outside the rucksack for smaller items.
- Attach additional gear using the MOLLE attachment points as needed.

Disposal Instructions

- **Environmental Responsibility:** When disposing of the VORN EV30 Rucksack, please follow local regulations for textile and plastic waste disposal.
- **Recycling:** If possible, recycle components such as fabric and zippers to minimize environmental impact.

Contact Information for Further Support

For further assistance or inquiries regarding safety, please refer to the contact information provided by the retailer or manufacturer. Always ensure you are using genuine VORN products for safety and reliability.

Thank you for your attention to these safety instructions. Enjoy your VORN EV30 Rucksack and have a safe and successful hunting experience!