

ZSM SHOTGUN FLASHLIGHT MOUNT - SHOTGUN FLASHLIGHT MOUNT

Made in the USA For Remington 870 & Mossberg 500/590 & other shotguns with extended magazine tubes Attaches to barrel & magazine tube Requires only 1 3/4" of free space on the barrel and magazine tube Also fits 20 gauge and .410 (gauge adapters included) Glass-filled polymer construction Fits most popular flashlights from .70 to 1.05" in diameter (sizing adapters included) Get the QD Sling Swivel Kit for ZSM Limited.



Attributes

- Name: SHOTGUN FLASHLIGHT MOUNT
- Manufacturer: ELZETTA MANUFACTURING
- Product no.: 100006660
- Mfr. No.: ZSM
- Finish: Black
- Style: Mount
- Delivery weight: 0.113kg
- Shipping height: 41mm
- Shipping width: 122mm
- Shipping length: 178mm

Item details

Made in USA
EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den ELZETTA MANUFACTURING ZSM Shotgun Flashlight Mount](#)
- [English: ZSM Shotgun Flashlight Mount Safety Instructions](#)

Sicherheitshinweise für den ELZETTA MANUFACTURING ZSM Shotgun Flashlight Mount

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des ELZETTA MANUFACTURING ZSM Shotgun Flashlight Mount! Dieses Produkt wurde entwickelt, um Ihnen eine sichere und zuverlässige Möglichkeit zu bieten, Ihre Taschenlampe an Schrotflinten wie dem Remington 870 und Mossberg 500/590 zu montieren. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um die sichere Verwendung und Installation des Produkts zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt für die Verwendung mit den angegebenen Schrotflinten geeignet ist.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und schutzbedürftigen Personen.
- Überprüfen Sie regelmäßig den Zustand des Mounts und der Taschenlampe auf Abnutzung oder Beschädigungen.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Stellen Sie sicher, dass der Mount fest am Lauf und Magazinrohr befestigt ist, bevor Sie die Taschenlampe verwenden.
- Verwenden Sie nur Taschenlampen mit einem Durchmesser von 0,70 bis 1,05 Zoll.
- Achten Sie darauf, dass der Mount nicht übermäßig belastet wird, um Beschädigungen zu vermeiden.
- Vermeiden Sie die Verwendung von Produkten, die Anzeichen von Beschädigung oder Abnutzung aufweisen.
- Verwenden Sie den Adapter für die Gauge (20 Gauge und .410) nur, wenn er ordnungsgemäß installiert ist.

Anweisungen zur Installation und Verwendung

1. Vorbereitung:

- Stellen Sie sicher, dass Sie alle Teile des Mounts und die erforderlichen Adapter zur Hand haben.
- Überprüfen Sie, ob der Bereich am Lauf und Magazinrohr mindestens 1 3/4 Zoll frei ist.

2. Installation:

- Befestigen Sie den Mount sicher am Lauf und Magazinrohr Ihrer Schrotflinte.
- Stellen Sie sicher, dass der Mount fest sitzt und keine Bewegung aufweist.
- Installieren Sie die Taschenlampe gemäß den Anweisungen des Herstellers und stellen Sie sicher, dass sie sicher im Mount sitzt.

3. Verwendung:

- Verwenden Sie die Taschenlampe nur, wenn sie ordnungsgemäß montiert ist.
- Überprüfen Sie regelmäßig, ob die Taschenlampe fest sitzt und der Mount in gutem Zustand ist.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektronik und Kunststoffabfälle.
- Stellen Sie sicher, dass alle Teile des Produkts ordnungsgemäß recycelt oder entsorgt werden, um Umweltschäden zu vermeiden.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken zu diesem Produkt wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Achten Sie darauf, alle relevanten Informationen über das Produkt bereitzustellen, um eine schnelle und effiziente Unterstützung zu erhalten.

Vielen Dank, dass Sie sich für den ELZETTA MANUFACTURING ZSM Shotgun Flashlight Mount entschieden haben. Ihre Sicherheit und Zufriedenheit sind uns wichtig!

ZSM Shotgun Flashlight Mount Safety Instructions

Introduction

Thank you for choosing the ZSM Shotgun Flashlight Mount. This product is designed to enhance your shotgun's functionality by securely mounting a flashlight. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Always handle the ZSM Shotgun Flashlight Mount with care.
- Ensure that the mount is compatible with your shotgun model before installation.
- Regularly inspect the mount for any signs of damage or wear.
- Keep the mount and flashlight out of reach of children.
- If you notice any irregularities during use, discontinue use immediately and consult a professional.

Specific Safety Precautions for Use

- Ensure the shotgun is unloaded before installing or adjusting the flashlight mount.
- Do not exceed the weight limit of the flashlight specified in this guide.
- Use only the recommended flashlight sizes, ranging from 0.70 to 1.05 inches in diameter.
- Follow all local laws and regulations regarding the use of firearms and accessories.
- Avoid exposing the mount to extreme temperatures or harsh chemicals.
- Do not modify the mount in any way, as this may compromise safety.

Instructions for Installation and Usage

Installation Steps

1. Prepare the Shotgun:

- Ensure the shotgun is completely unloaded.
- Clear the area of any obstructions.

2. Locate the Installation Area:

- Identify the barrel and magazine tube of your shotgun.
- Ensure there is at least 1 3/4 inches of free space on both the barrel and magazine tube.

3. Attach the Mount:

- Position the ZSM Shotgun Flashlight Mount on the barrel and magazine tube.
- Securely attach the mount, ensuring it is tight and stable.

4. Install the Flashlight:

- Insert the flashlight into the mount, ensuring it fits snugly.
- Use the sizing adapters provided if necessary.

5. Final Checks:

- Ensure the mount and flashlight are securely attached before use.
- Test the flashlight to confirm it is functioning properly.

Usage Instructions

- To operate the flashlight, follow the manufacturer's instructions for the specific flashlight model.
- Regularly check the flashlight's battery and replace it as needed.
- Avoid using the flashlight in conditions that may impair visibility or safety.

Disposal Instructions

- Dispose of the ZSM Shotgun Flashlight Mount in accordance with local regulations.
- Do not dispose of the mount in regular household waste.
- If the mount is damaged or no longer in use, consider recycling it if possible.

Contact Information for Further Support

For any questions or concerns regarding the ZSM Shotgun Flashlight Mount, please refer to the manufacturer's website or contact customer support directly.

Thank you for prioritizing safety while using the ZSM Shotgun Flashlight Mount. Your adherence to these guidelines helps ensure a safe and enjoyable experience.