

C-4 MONOLITHIC CHASSIS FOR REMINGTON 700 SHORT ACTION - KINETIC RESEARCH GROUP C-4 CHASSIS REM700 SA W/EXT OPT SHROUD/THUMBGRIP/OVERMOLDED

KINETIC RESEARCH GROUP C-4 MONOLITHIC CHASSIS FOR REMINGTON 700 SA

Purpose built with direct feedback from top competitors and trainers the C-4 is the epitome of the modern competition rifle chassis. With sought after features such as tool-less adjustable length of pull, cheekpiece, height and cant, as well as their new bag rider height adjustment, this chassis is designed to fit the shooter for maximum comfort and repeatability. KRG also included height and tension adjustment for your magazine to adjust for the many variations that can occur allowing your preferred AICS or AW mag to fit and feed just right. The C-4 features a full monolithic aluminum frame, an extended 16 3/4" forend, and an integral ARCA Rail making it extremely rigid and resistant to variations. If you are looking for the ultimate competition chassis the C-4 is ready to go for your next rifle build. SPECS Fits: Remington 700 SA/LA, Tikka T3 (including T3x and CTR) and most clones. **Lone Peak actions may require bedding** Grip: Thumbshelf Grip Barrel Shroud: Optic Inlet Shroud or Extended Optic Inlet Shroud Cheekpiece: Enhanced or Overmolded Magazine: Short Action - AICS or AW pattern, Tikka T3 CTR magazine. Materials: Anodized Aluminum. Weight: 6.3 lbs chassis w/o magazine. Color: Black



Attributes

- Name: KINETIC RESEARCH GROUP C-4 CHASSIS REM700 SA W/EXT OPT SHROUD/THUMBGRIP/OVERMOLDED
- Manufacturer: KINETIC RESEARCH GROUP
- Product no.: 430115493
- Mfr. No.: C4X-R7S-XTO
- Action Type: Short
- Colour: Black
- Material: Aluminum
- Model: 700
- Style: Chassis
- Weapon type: Remington
- Weight: 6.3 lbs
- Delivery weight: 3.629kg
- Shipping height: 914mm
- Shipping width: 178mm
- Shipping length: 102mm

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: C4 Monolithic Chassis Safety Instruction Guide](#)

C4 Monolithic Chassis Safety Instruction Guide

Introduction

Thank you for choosing the C4 Monolithic Chassis for your Remington 700 Short Action rifle. This guide provides essential safety instructions to ensure the safe and effective use of your chassis. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure the chassis is compatible with your specific rifle model.
- Always handle the chassis and firearm with care to avoid accidental discharge.
- Keep the chassis and firearm out of reach of children and unauthorized users.
- Regularly inspect the chassis for wear and tear, ensuring all components are functioning correctly.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Handling:** Always treat the chassis as if it is loaded. Keep your finger off the trigger until you are ready to shoot.
- **Installation:** Follow the installation instructions carefully to avoid improper fitting, which could lead to malfunctions.
- **Adjustments:** Make all adjustments (length of pull, cheekpiece height, etc.) while the firearm is unloaded and pointed in a safe direction.
- **Magazine Compatibility:** Ensure that the magazine used is compatible with the chassis to prevent feeding issues.
- **Shooting Environment:** Only use the chassis in designated shooting areas and ensure that the environment is safe for shooting.

Instructions for Installation and Usage

1. Installation:

- Remove the existing stock from your Remington 700 Short Action rifle.
- Align the chassis with the action of the rifle, ensuring that all mounting points are correctly positioned.
- Secure the chassis using the provided screws and tools, ensuring a tight fit.
- Install the magazine, ensuring it locks into place properly.

2. Adjustments:

- **Length of Pull:** Adjust the length of pull using the toolless mechanism on the chassis.
- **Cheekpiece:** Adjust the cheekpiece height and cant to achieve a comfortable shooting position.
- **Bag Rider:** Adjust the bag rider height to suit your shooting style and preference.

3. Usage:

- Before shooting, ensure that the rifle is unloaded and check all adjustments.
- When ready to shoot, assume a stable shooting position and ensure the firearm is aimed safely.
- After shooting, always check the chassis and firearm for any signs of damage or wear.

Disposal Instructions

- Dispose of the chassis in accordance with local regulations regarding metal and aluminum waste.
- If the chassis is damaged beyond use, contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries or further assistance regarding the C4 Monolithic Chassis, please refer to the manufacturer's contact points provided in the product packaging or on the official website.

By following these safety instructions, you can ensure a safe and enjoyable experience with your C4 Monolithic Chassis. Thank you for prioritizing safety and responsible usage.