

HAMMER FOR REMINGTON VERSA MAX UNFINISHED

REMINGTON HAMMER FOR REMINGTON VERSA MAX The Remington Hammer is a genuine OEM replacement component designed for the Remington Versa Max shotgun. Manufactured from raw, unfinished steel, this hammer is a critical part of the fire control system, delivering reliable ignition and consistent performance. Ideal for maintenance, repair, or restoration, it provides factory-correct fit and dependable operation. FEATURES Genuine Remington OEM Part - Built to factory specifications for precise fit and reliable function Designed for Remington Versa Max - Ensures proper compatibility with Versa Max shotguns Raw Unfinished Steel Construction - Durable steel suitable for factory installation or gunsmith fitting Critical Fire Control Component - Delivers consistent primer strikes for dependable ignition Ideal for Repair or Restoration - Perfect for replacing worn, damaged, or missing hammers SPECS Manufacturer: Remington Model Compatibility: Remington Versa Max Part Type: Hammer Material: Steel Finish: Raw / Unfinished Color: Steel OEM: Yes NOTE: These items are a new, authentic products acquired directly from Remington's OEM inventory. This item is guaranteed to be unused and fully functional.

NO IMAGE
AVAILABLE

Attributes

- Name: HAMMER FOR REMINGTON VERSA MAX UNFINISHED
- Manufacturer: REMINGTON
- Product no.: 430116806
- Mfr. No.: F407220
- Model: Versamax
- Weapon type: Remington
- Shipping height: 18mm
- Shipping width: 4mm
- Shipping length: 48mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Remington Versa Max Hammer](#)

Safety Instruction Guide for Remington Versa Max Hammer

Introduction

Thank you for choosing the Remington Hammer for the Versa Max shotgun. This guide provides essential safety instructions and guidelines to ensure the safe use and installation of this product. Please read and follow these instructions carefully to ensure proper handling and maintenance.

General Safety Guidelines

- Always handle firearms and their components with care and respect.
- Ensure that the firearm is unloaded and safe before beginning any maintenance or installation work.
- Store the hammer and all firearm components in a secure location, out of reach of children and unauthorized users.
- Regularly inspect all components for wear or damage before use.
- Follow all local laws and regulations regarding firearms and their components.
- In case of any doubts or concerns regarding safety, consult a qualified gunsmith or firearms expert.

Specific Safety Precautions for Use

- Use only in compatible Remington Versa Max shotguns to ensure proper function.
- Avoid using the hammer if it shows signs of damage or excessive wear.
- Do not modify the hammer or any firearm components, as this may create safety hazards.
- Always wear appropriate safety gear, such as eye protection, when working with firearms.
- Keep the work area clean and free of distractions to maintain focus during installation or maintenance.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the shotgun is completely unloaded and the chamber is clear.
- Gather all necessary tools for installation, including screwdrivers and any other required equipment.

2. Removing the Old Hammer:

- Disassemble the shotgun according to the manufacturer's instructions.
- Carefully remove the old hammer from the fire control system, taking note of the order of components for reassembly.

3. Installing the New Hammer:

- Take the new Remington Hammer and align it with the fire control system.
- Securely attach the hammer following the original assembly instructions, ensuring all components are correctly positioned.
- Doublecheck that all connections are tight and secure.

4. Reassembling the Shotgun:

- Reassemble the shotgun according to the manufacturer's guidelines.
- After reassembly, perform a function check to ensure that the hammer operates correctly.

5. Final Inspection:

- Inspect the shotgun to ensure that all parts are functioning properly and that there are no loose components.
- Store the shotgun in a safe and secure manner.

Disposal Instructions

- Dispose of any old or damaged components in accordance with local regulations for hazardous waste.
- Do not throw away firearm parts in regular trash; consult local authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the Remington Hammer for the Versa Max shotgun, please refer to the official Remington website or contact their customer support for assistance.

By following these safety guidelines and instructions, you can ensure the proper use and maintenance of your Remington Hammer for the Versa Max shotgun. Your safety is our priority, and we appreciate your commitment to responsible firearm handling.