

MESA CHS .308 FDE

Christensen Arms MESA CHS .308 with MAGPUL Rem 700 SA Hunter Stock



The Christensen Arms MESA CHS .308 is a highly precise, powerful hunting and sporting rifle, built from a proven combination of barreled action and high-quality stock.

The short action barreled action, made of durable 416T stainless steel, is chambered in .308 Winchester and features a 22-inch stainless steel barrel with a 1:10 twist rate. The Cerakote coating in tungsten reliably protects against corrosion and wear.

The MAGPUL Rem 700 SA Hunter stock provides a stable and ergonomic base with an adjustable length of pull for optimal comfort and control. Made from reinforced polymer, it allows for easy "drop-in" installation without additional bedding. M-LOK interfaces enable accessory mounting, and the system is compatible with detachable box magazines.

Technical Data:

- **Type:** Bolt-Action Rifle
- **Action:** Short Action
- **Barrel:** Threaded, Stainless Steel
- **Finish:** Cerakote Tungsten
- **Model:** Remington 700 Compatible
- **Contour:** Sporter
- **Barrel Length:** 559 mm (22")
- **Caliber:** .308 Winchester
- **Twist Rate:** 1:10
- **Capacity:** 5 Rounds
- **Stock Type:** Adjustable, Short Action
- **Stock Color:** Black/FDE/O.D Green

Stock Material: High-Strength Polymer

Installed items:

- CHRISTENSEN ARMS MESA 308 WIN BBL ACTION 22" 1-10 SPORTER CONTOUR TUNGSTEN - **430102971**
- TRIGGERTECH Rem700 Primary - Traditional Curved - **EU2010009**
- MAGPUL Rem 700SA Hunter Schaft einstellbar - **100016643/100016644/100016646**
- Rem. 700 SA Scope Base, 20 MOA - **080000761**
- MDT AICS Magazine 308/6.5 Creedmoor 5 Rounds - **EU2009729**

Attributes

- Name: Christensen Arms MESA CHS .308 FDE
- Manufacturer: Christensen Arms

- Product no.: BRD112053
- Mfr. No.:
- Action Type: Short
- Barrel Length: 22"
- Barrel Type: Threaded
- Caliber: .308
- Capacity: 5-Round
- Color: Flat Dark Earth, FDE
- Make: Christensen Arms
- Material: 6061 Aluminum
- Model: Remington 700
- Mount: Picatinny
- Twist Rate: 1-10
- Delivery weight: 3.6kg
- Shipping height: 89mm
- Shipping width: 89mm
- Shipping length: 919mm

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das Christensen Arms MESA CHS .308](#)
- [English: Safety Instruction Guide for Christensen Arms MESA CHS .308](#)

Sicherheitshinweise für das Christensen Arms MESA CHS .308

Einleitung

Vielen Dank, dass Sie sich für das Christensen Arms MESA CHS .308 entschieden haben. Dieses hochpräzise Jagd und Sportgewehr wurde entwickelt, um Ihnen eine sichere und angenehme Schießerfahrung zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen.

Allgemeine Sicherheitsrichtlinien

- **Produktverantwortung:** Stellen Sie sicher, dass Sie das Gewehr gemäß den Anweisungen und Sicherheitsrichtlinien verwenden.
- **Aufbewahrung:** Lagern Sie das Gewehr immer in einem sicheren, verschlossenen Bereich, der für Kinder unzugänglich ist.
- **Sichtprüfung:** Überprüfen Sie das Gewehr vor jeder Benutzung auf sichtbare Schäden oder Mängel.
- **Sicherheitsvorrichtungen:** Nutzen Sie die Sicherheitsvorrichtungen des Gewehrs und stellen Sie sicher, dass diese in einwandfreiem Zustand sind.
- **Schutzkleidung:** Tragen Sie beim Schießen geeignete Schutzkleidung, einschließlich Gehörschutz und Schutzbrille.
- **Umgebung:** Schießen Sie nur in ausgewiesenen und sicheren Bereichen, die für das Schießen geeignet sind.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- **Munition:** Verwenden Sie nur die vom Hersteller empfohlene Munition (.308 Winchester) und überprüfen Sie die Munition auf Beschädigungen.
- **Handhabung:** Behandeln Sie das Gewehr immer so, als wäre es geladen. Halten Sie den Lauf niemals auf etwas, was Sie nicht treffen möchten.
- **Zielidentifikation:** Vergewissern Sie sich, dass sich keine Personen oder Tiere im Schussfeld befinden, bevor Sie abdrücken.
- **Sichtprüfung nach dem Schießen:** Überprüfen Sie das Gewehr nach dem Schießen auf Rückstände oder Schäden.
- **Wartung:** Halten Sie das Gewehr sauber und gut gewartet, um die Sicherheit und Leistung zu gewährleisten.

Anweisungen für Installation und Nutzung

Installation des MAGPUL Rem 700 SA Hunter Schaft

1. **Vorbereitung:** Stellen Sie sicher, dass das Gewehr entladen ist und sich in einem sicheren Zustand befindet.
2. **Entfernen des alten Schafts:** Lösen Sie die Schrauben, die den alten Schaft halten, und entfernen Sie diesen vorsichtig.
3. **Einsetzen des neuen Schafts:** Setzen Sie den MAGPUL Rem 700 SA Hunter Schaft an die entsprechende Stelle und stellen Sie sicher, dass er richtig sitzt.
4. **Befestigung:** Ziehen Sie die Schrauben gleichmäßig und fest an, um eine sichere Verbindung zu gewährleisten.
5. **Einstellen:** Passen Sie die Schaftlänge an Ihre Bedürfnisse an.

Nutzung des Gewehrs

1. **Laden:** Laden Sie das Gewehr gemäß den Anweisungen im Benutzerhandbuch.
2. **Zielen:** Nehmen Sie eine stabile Schießposition ein und zielen Sie auf das gewünschte Ziel.
3. **Abdrücken:** Atmen Sie tief durch, halten Sie den Abzug sanft gedrückt und drücken Sie ab.
4. **Nach dem Schießen:** Entladen Sie das Gewehr und überprüfen Sie es nach jedem Schuss auf mögliche Probleme.

Entsorgungsanweisungen

- **Umweltgerechte Entsorgung:** Entsorgen Sie das Gewehr und alle Zubehörteile gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- **Waffenrückgabe:** Bei einer Rückgabe oder Entsorgung des Gewehrs wenden Sie sich an die zuständigen Behörden oder Fachhändler.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung zu Sicherheitsfragen kontaktieren Sie bitte den Kundenservice von Christensen Arms oder besuchen Sie die offizielle Website des Herstellers.

Bitte beachten Sie, dass Sie alle Sicherheitsanweisungen und Richtlinien befolgen sollten, um Ihre Sicherheit und die Sicherheit anderer zu gewährleisten. Bei Fragen oder Unsicherheiten zögern Sie nicht, professionelle Hilfe in Anspruch zu nehmen.

Safety Instruction Guide for Christensen Arms MESA CHS .308

Introduction

Thank you for choosing the Christensen Arms MESA CHS .308. This guide provides essential safety instructions to ensure the safe use and maintenance of your rifle. Please read this guide carefully and follow all instructions to minimize risks and enhance your shooting experience.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the muzzle in a safe direction.
- Be aware of your target and what is beyond it.
- Store your firearm securely to prevent unauthorized access.
- Use only the recommended ammunition for your rifle.
- Regularly inspect your firearm for any signs of wear or damage.
- Always wear appropriate eye and ear protection when shooting.
- Ensure that children and unauthorized individuals are kept away from firearms.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- **Handling:**
 - Always handle the rifle with care and respect.
 - Do not engage in horseplay while handling firearms.
- **Shooting Location:**
 - Only shoot in designated areas where shooting is permitted.
 - Ensure the shooting range is safe and free of obstructions.
- **Weather Conditions:**
 - Avoid using the rifle in adverse weather conditions (e.g., heavy rain, strong winds).
- **Maintenance:**
 - Regularly clean and maintain your rifle as per the manufacturer's guidelines.
 - Do not attempt to modify or alter the rifle without consulting a qualified gunsmith.

Instructions for Installation and Usage

- **Installation of Accessories:**
 - Ensure the rifle is unloaded before any installation.
 - Follow the manufacturer's instructions for attaching accessories such as scopes or bipods.
 - Use the MLOK interfaces for mounting accessories securely.
- **Loading the Rifle:**
 - Ensure the safety is engaged before loading the rifle.
 - Insert the magazine into the rifle until it clicks into place.
 - Pull the bolt back and release it to chamber a round.
- **Shooting:**
 - Position yourself comfortably and ensure a stable shooting stance.
 - Align your sights with the target and gently squeeze the trigger.
- **Unloading the Rifle:**
 - Engage the safety before attempting to unload.
 - Remove the magazine and pull the bolt back to eject any chambered round.
 - Visually inspect the chamber to ensure it is clear.

Disposal Instructions

- Dispose of the rifle responsibly and in accordance with local regulations.
- Do not discard ammunition in regular trash. Contact local authorities for proper disposal procedures.
- If the rifle is damaged or no longer functional, consult a qualified professional for safe disposal options.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of your Christensen Arms MESA CHS .308, please refer to the manufacturer's official website or contact their support team for assistance.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable experience with your Christensen Arms MESA CHS .308 rifle. Always prioritize safety and responsibility in all aspects of firearm use.