

KMR Tuningspringset - KMR Precision Arms - Tuningspringset - Double Action

Tuning spring set for your KMR pistol!

Consisting of a firing pin spring and a impact spring.



Attributes

- Name: KMR Precision Arms - Tuningspringset - Double Action
- Manufacturer: KMR Precision Arms
- Product no.: BRD113037
- Mfr. No.: D001-00001-0009
- Make: KMR Precision Arms
- Delivery weight: 0.1kg

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den KMR Tuningfedersatz](#)
- [English: KMR Tuningspringset Safety Instruction Guide](#)

Sicherheitshinweise für den KMR Tuningfedersatz

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des KMR Tuningfedersatzes! Dieses Produkt wurde entwickelt, um die Leistung Ihrer KMR Pistole zu optimieren. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Produkt nur für den vorgesehenen Zweck verwendet wird.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und schutzbedürftigen Personen.
- Überprüfen Sie regelmäßig den Zustand des Tuningfedersatzes, um sicherzustellen, dass er in einwandfreiem Zustand ist.
- Melden Sie unsichere Produkte oder Unfälle unverzüglich den zuständigen Behörden.
- Informieren Sie sich über Rückrufupdates auf der EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie den Tuningfedersatz nur mit KMR Pistolen.
- Stellen Sie sicher, dass die Pistole vor der Installation des Tuningfedersatzes entladen ist.
- Tragen Sie geeignete Schutzausrüstung, wie z.B. Schutzbrille, während der Installation.
- Vermeiden Sie es, den Tuningfedersatz zu modifizieren oder zu reparieren, da dies zu gefährlichen Situationen führen kann.

Anweisungen zur Installation und Verwendung

1. Vorbereitung

- Stellen Sie sicher, dass Sie alle benötigten Werkzeuge zur Hand haben.
- Überprüfen Sie, dass die Pistole entladen ist.

2. Installation

- Entfernen Sie die Abzugsgruppe gemäß den Anweisungen des Herstellers.
- Tauschen Sie die vorhandene Schlagbolzenfeder und Schlagfeder gegen die neuen Teile aus dem Tuningfedersatz aus.
- Setzen Sie die Abzugsgruppe wieder in die Pistole ein und stellen Sie sicher, dass alles korrekt sitzt.

3. Verwendung

- Testen Sie die Pistole in einem sicheren und kontrollierten Umfeld, um sicherzustellen, dass der Tuningfedersatz ordnungsgemäß funktioniert.
- Achten Sie auf ungewöhnliche Geräusche oder Verhaltensweisen während der Verwendung und stoppen Sie die Nutzung, falls diese auftreten.

Entsorgungsanweisungen

- Entsorgen Sie den Tuningfedersatz gemäß den geltenden lokalen Vorschriften für Elektroschrott und gefährliche Abfälle.
- Stellen Sie sicher, dass alle Teile sicher und umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

- Für Fragen oder weitere Informationen zum KMR Tuningfedersatz wenden Sie sich bitte an den Hersteller oder autorisierte Händler.

Bitte beachten Sie, dass die Sicherheit und der ordnungsgemäße Gebrauch Ihrer KMR Pistole von größter Bedeutung sind. Befolgen Sie diese Anweisungen sorgfältig, um sicherzustellen, dass Sie das Beste aus Ihrem Produkt herausholen.

KMR Tuningspringset Safety Instruction Guide

Introduction

Thank you for choosing the KMR Tuningspringset from KMR Precision Arms. This tuning spring set is designed for your KMR pistol and consists of a firing pin spring and an impact spring. To ensure safe and effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Ensure the product is used only as intended for your KMR pistol.
- Always handle the tuning spring set with care to avoid injury.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the springs regularly for signs of wear or damage before use.
- If you notice any abnormalities, do not use the product and seek professional assistance.

Specific Safety Precautions for Use

- Only use the tuning spring set with compatible KMR pistols.
- Do not modify the springs or use them in any way not specified by the manufacturer.
- Wear appropriate safety gear, such as eye protection, when handling or installing the springs.
- Always ensure the pistol is unloaded before installing or replacing the tuning springs.
- Follow the manufacturer's instructions carefully during installation to prevent accidents.

Instructions for Installation and Usage

1. Preparation:

- Ensure you have the necessary tools for installation.
- Work in a clean, welllit area free from distractions.

2. Installation Steps:

- Unload your KMR pistol and ensure it is pointed in a safe direction.
- Remove the existing tuning springs from the pistol according to the manufacturer's guidelines.
- Carefully install the new firing pin spring by aligning it with the designated slot.
- Install the impact spring in the same manner, ensuring it is seated correctly.
- Doublecheck that both springs are securely in place before reassembling the pistol.

3. PostInstallation:

- After installation, conduct a function check to ensure the pistol operates correctly.
- If any issues arise, consult a qualified gunsmith or contact the manufacturer for assistance.

Disposal Instructions

- Dispose of any old springs or packaging materials in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, use designated recycling facilities if available.

Contact Information for Further Support

For any questions or concerns regarding the KMR Tuningspringset, please reach out to the manufacturer or consult the official website for additional support and resources.

Thank you for prioritizing safety while using the KMR Tuningspringset. Your adherence to these guidelines helps ensure a safe and enjoyable experience with your KMR pistol.