

American Rifle Predator - 6.5 Creemoor 4Rd

Ruger American Rifle Predator



The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3-5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: RUGER - American Rifle Predator - 6.5 Creemoor 4Rd
- Manufacturer: RUGER
- Product no.: BRD113083
- Mfr. No.: 17903186
- Barrel Finish: Matte Black
- Barrel Length: 22"
- Caliber: 6.5 Creedmoor
- Capacity: 4-Round
- Color: Moss Green
- Length: 42"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 5/8-24
- Side: Right
- Twist Rate: 1-8
- Weight: 6.6 lbs
- Delivery weight: 3kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 1,067mm
- UPC: 736676069736

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Ruger American Rifle Predator](#)
- [English: Ruger American Rifle Predator Safety Instruction Guide](#)

Sicherheitshinweise für die Ruger American Rifle Predator

Einleitung

Herzlichen Glückwunsch zum Kauf Ihrer Ruger American Rifle Predator! Dieses Produkt wurde für Präzision und Robustheit entwickelt und eignet sich ideal für Varmintjagd und präzises LongRangeSchießen. Um sicherzustellen, dass Sie und andere sicher mit diesem Produkt umgehen, beachten Sie bitte die folgenden Sicherheitshinweise.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass alle nichtlebensmittelbezogenen Produkte, einschließlich neuer Technologien und OnlineKäufe, sicher verwendet werden.
- Überprüfen Sie regelmäßig auf Rückrufinformationen, um sicherzustellen, dass Ihr Produkt sicher ist.
- Nutzen Sie OnlinePlattformen mit den gleichen Sicherheitsanforderungen wie physische Geschäfte.
- Seien Sie besonders vorsichtig, wenn Kinder oder andere gefährdete Gruppen in der Nähe sind.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.
- Halten Sie sich über die Sicherheitswarnungen auf der EU Safety GatePlattform auf dem Laufenden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Halten Sie die Waffe immer in einem sicheren Zustand, insbesondere wenn sie nicht in Gebrauch ist.
- Überprüfen Sie vor jedem Gebrauch, ob die Waffe ordnungsgemäß funktioniert.
- Verwenden Sie nur die empfohlenen Munitionstypen für Ihr Kaliber.
- Halten Sie den Abzug immer vom Finger fern, bis Sie bereit sind, zu schießen.
- Achten Sie darauf, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Anweisungen für Installation und Nutzung

• Installation:

- Stellen Sie sicher, dass der Lauf und das Mündungsgewinde sauber sind, bevor Sie Zubehör wie Schalldämpfer anbringen.
- Befestigen Sie die WeaverSchiene sicher, um Zubehör wie Zielfernrohre zu montieren.

• Benutzung:

- Stellen Sie sicher, dass das Magazin korrekt eingesetzt ist, bevor Sie die Waffe laden.
- Überprüfen Sie, ob die Schiebesicherung am Kolbenhals in der sicheren Position ist, wenn Sie die Waffe nicht verwenden.
- Führen Sie regelmäßige Wartungsarbeiten durch, um die Leistung der Waffe zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie leere Patronen und andere Waffenabfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass die Waffe vor der Entsorgung entladen ist.
- Bringen Sie die Waffe nur zu autorisierten Rücknahmestellen zur Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu Ihrer Ruger American Rifle Predator, wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt erworben haben. Achten Sie darauf, alle Sicherheitsrichtlinien zu befolgen, um eine sichere Nutzung zu gewährleisten.

Ruger American Rifle Predator Safety Instruction Guide

Introduction

Thank you for choosing the Ruger American Rifle Predator. This guide provides essential safety instructions to ensure your safe and responsible use of this firearm. Please read this manual thoroughly before using the rifle.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Ensure your finger is off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Store firearms securely to prevent unauthorized access, especially from children.
- Use appropriate ammunition for your firearm. The Ruger American Rifle Predator is designed for 6.5 Creedmoor caliber.
- Regularly inspect your firearm for any signs of wear or damage.
- Wear appropriate eye and ear protection when shooting.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- **Ergonomic Stock:** Ensure the stock fits comfortably against your shoulder to maintain control and accuracy.
- **Adjustable Trigger:** Familiarize yourself with the Ruger Marksman Adjustable Trigger. Adjust it to your preferred weight between 1.4 and 2.3 kg (3-5 lbs) using the adjustment key stored in the bolt.
- **Muzzle Threads:** Ensure that any muzzle device you attach is securely fastened and appropriate for the 5/824 threads.
- **Twist Rate:** Use bullets that are suitable for the 18 twist rate of the barrel to optimize accuracy.

Instructions for Installation and Usage

1. Installation of Accessories:

- Ensure the rifle is unloaded before installing any accessories.
- Follow the manufacturer's instructions for installing scopes, bipods, or other accessories.

2. Loading the Rifle:

- Open the bolt and visually inspect the chamber to ensure it is clear.
- Insert the magazine into the magazine well until it clicks into place.
- Load cartridges into the magazine, ensuring they are seated correctly.
- Close the bolt to chamber a round.

3. Shooting:

- Position yourself in a stable shooting stance.
- Align your sights with your target.
- Squeeze the trigger gently to fire the rifle.
- After firing, maintain control of the rifle and be aware of the surroundings.

4. Unloading the Rifle:

- Point the rifle in a safe direction.
- Open the bolt to eject any chambered round.
- Remove the magazine and ensure all cartridges are removed.

5. Cleaning and Maintenance:

- Clean your rifle regularly to maintain optimal performance.
- Use a cleaning kit suitable for the 6.5 Creedmoor caliber.
- Inspect the rifle for any signs of wear or damage after each use.

Disposal Instructions

- Dispose of any unused or expired ammunition following local regulations.
- Do not dispose of firearms in regular trash. Contact local authorities for proper disposal methods.
- Ensure that all components of the firearm are disposed of in a safe and environmentally friendly manner.

Contact Information for Further Support

For more information regarding safety or product inquiries, please refer to the manufacturer's website or contact the retailer from whom you purchased the Ruger American Rifle Predator.

Thank you for prioritizing safety and responsibility while enjoying your Ruger American Rifle Predator. Always remember to follow these guidelines to ensure a safe shooting experience.