

American Rifle Predator - .223 Rem.

Ruger American Rifle Predator



The Ruger American Rifle Predator combines cutting-edge innovation with Ruger's renowned reliability. Manufactured 100% in the USA, this bolt-action rifle offers exceptional precision and handling.

- **Ergonomic Stock:** Lightweight synthetic stock with a classic design, modern forend styling, and textured grip areas for superior control.
- **Adjustable Trigger:** The Ruger Marksman Adjustable Trigger is externally adjustable between 1.4 and 2.3 kg (3-5 lbs), with the adjustment key securely stored in the bolt.
- **Versatile Performance:** Ideal for hunting and precision shooting under various conditions.

Attributes

- Name: RUGER - American Rifle Predator - .223 Rem.
- Manufacturer: RUGER
- Product no.: BRD113085
- Mfr. No.: 17904105
- Barrel Finish: Matte Black
- Barrel Length: 22"
- Caliber: .223Rem
- Capacity: 10-Round
- Color: Moss Green
- Length: 42"
- Make: Ruger
- Material: Alloy Steel
- Model: American Predator
- Muzzle Threads: 1/2-28
- Side: Right
- Twist Rate: 1-8
- Weight: 6.6 lbs
- Delivery weight: 3kg
- Shipping height: 200mm
- Shipping width: 25mm
- Shipping length: 1,067mm
- UPC: 736676269440

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Ruger American Rifle Predator](#)
- [English: Ruger American Rifle Predator Safety Instructions](#)

Sicherheitshinweise für die Ruger American Rifle Predator

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf der Ruger American Rifle Predator im Kaliber .223 Rem. Diese Anleitung soll Ihnen helfen, das Produkt sicher und effektiv zu nutzen. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um Risiken zu vermeiden und die Lebensdauer Ihres Gewehrs zu maximieren.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck und gemäß den Anweisungen in dieser Anleitung.
- Halten Sie das Gewehr immer in einem sicheren Zustand, wenn es nicht verwendet wird.
- Bewahren Sie das Gewehr an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Überprüfen Sie das Gewehr regelmäßig auf Anzeichen von Verschleiß oder Beschädigung.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Besondere Sicherheitsvorkehrungen bei der Nutzung

- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, beim Schießen.
- Achten Sie darauf, dass sich keine Personen im Schussfeld befinden.
- Verwenden Sie nur die empfohlenen Munitionstypen für das Gewehr.
- Stellen Sie sicher, dass das Gewehr vor dem Laden und Entladen immer in einem sicheren Zustand ist.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern oder unbefugten Personen.

Anweisungen zur Installation und Nutzung

• Installation:

- Überprüfen Sie, ob alle Teile des Gewehrs vorhanden und unbeschädigt sind.
- Montieren Sie die Zielfernrohrschiene gemäß den Herstelleranweisungen.

• Nutzung:

- Laden Sie das Gewehr nur in einem sicheren, kontrollierten Bereich.
- Stellen Sie sicher, dass der Abzug nicht versehentlich betätigt wird, während Sie das Gewehr laden oder entladen.
- Schießen Sie nur auf ausgewiesenen Schießständen oder in sicheren, genehmigten Bereichen.
- Reinigen Sie das Gewehr regelmäßig, um die Funktionalität und Sicherheit zu gewährleisten.

Entsorgungsanweisungen

- Entsorgen Sie alle nicht mehr benötigten Teile und Munition gemäß den örtlichen Gesetzen und Vorschriften.
- Bringen Sie das Gewehr zu einem autorisierten Fachhändler oder einer Sammelstelle, wenn Sie es nicht mehr benötigen.

Kontaktinformationen für weitere Unterstützung

Für Fragen zur Sicherheit oder zur Verwendung Ihres Gewehrs wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler. Achten Sie darauf, dass Sie alle relevanten Informationen zur Hand haben, wenn Sie Unterstützung benötigen.

Bitte beachten Sie, dass die Einhaltung dieser Sicherheitshinweise nicht nur Ihre Sicherheit, sondern auch die Sicherheit anderer gewährleistet. Genießen Sie das Schießen mit Ihrer Ruger American Rifle Predator verantwortungsbewusst!

Ruger American Rifle Predator Safety Instructions

Introduction

Thank you for choosing the Ruger American Rifle Predator. This document provides essential safety instructions to ensure the safe use of your firearm. Please read and understand these guidelines thoroughly before using the product.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Ensure that you are in a safe environment when handling or firing your rifle.
- Store the firearm securely and out of reach of children and unauthorized users.
- Regularly inspect your firearm for any signs of wear or damage.

Specific Safety Precautions for Use

- **Age Restrictions:** This firearm is intended for use by individuals aged 18 and older. Ensure that minors are supervised by a qualified adult at all times.
- **Protective Gear:** Always wear appropriate eye and ear protection when shooting.
- **Ammunition:** Only use .223 Rem ammunition as specified for this rifle. Using incorrect ammunition can lead to malfunctions or accidents.
- **Weather Conditions:** Avoid using the firearm in adverse weather conditions, such as heavy rain or strong winds, which may affect accuracy and safety.
- **Shooting Range:** Always use the rifle at a designated shooting range that complies with local laws and regulations.

Instructions for Installation and Usage

1. Installation:

- Ensure the rifle is unloaded before installation.
- Attach any accessories (if applicable) according to the manufacturer's instructions.
- Check that all components are securely fastened and functioning properly.

2. Usage:

- Load the rifle following the manufacturer's guidelines.
- Ensure the safety mechanism is engaged until you are ready to fire.
- Use a stable shooting position to enhance accuracy and control.
- After firing, always check the chamber to confirm the rifle is empty before handling or storing.

Disposal Instructions

- Dispose of any unused or expired ammunition according to local regulations.
- When disposing of the rifle, contact a certified firearms dealer or local law enforcement for guidance on safe disposal methods.
- Never dispose of firearms in regular waste.

Contact Information for Further Support

For any inquiries regarding safety or product support, please reach out to the designated EU contact point for your product. Ensure you have your product details available for assistance.

Conclusion

Your safety and the safety of those around you are paramount. By following these guidelines, you can enjoy the Ruger American Rifle Predator responsibly and safely. Always stay informed about safety practices and updates regarding your firearm.