

Jack 7,62x39 Holz, Extended - Magazinhalter und Feuerwahlhebel

Attention: The weapon is not approved for sport shooting.

The weapon is approved for hunting shooting only.



Classic version of the "Jack" rifle with wooden stock.

- Particularly high production quality
- Original AKM barrel length of 415 mm
- Completely civilian new production in Rogów, Poland, no surplus parts
- Nitrated barrel from civilian Radom production
- Standard AK magazines fit
- Beautiful newly made wooden stock
- With standard AK 45° muzzle brake on standard AK muzzle thread
- PSO rail available on the side for installing optics
- Extended safety for simplified operation
- Extended magazine release lever for simplified operation
- Included 10-Round Magazin

Attributes

- Name: Jack 7,62x39 Holz, Extended - Magazinhalter und Feuerwahlhebel
- Manufacturer: WBP
- Product no.: BRD130001
- Mfr. No.: 100
- Accessory Rail: Yes
- Barrel Length: 16.33"
- Caliber: 7.62x39 (.310)
- Make: WBP
- Material: Wood, Steel
- Model: Jack 7,62x39 Holz
- Muzzle Threads: 14x1
- Rounds: 10-Round
- Delivery weight: 3.6kg

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel](#)
- [English: Safety Instruction Guide for Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel](#)

Sicherheitshinweise für den Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel

Einleitung

Vielen Dank, dass Sie sich für den Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel entschieden haben. Dieses Produkt ist für das jagdliche Schießen konzipiert und bietet eine hochwertige Fertigungsqualität. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt nur von befugten Personen verwendet wird.
- Bewahren Sie das Produkt außerhalb der Reichweite von Kindern auf.
- Überprüfen Sie regelmäßig auf Beschädigungen oder Abnutzung.
- Informieren Sie sich über die örtlichen Gesetze und Vorschriften zum Schießen.
- Melden Sie unsichere Produkte oder Unfälle an die zuständigen Behörden.

Besondere Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Tragen Sie beim Schießen immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Achten Sie darauf, dass der Lauf stets sauber und frei von Verunreinigungen ist.
- Stellen Sie sicher, dass sich keine Personen oder Tiere in der Nähe des Schießbereichs befinden.
- Halten Sie den Finger immer vom Abzug, bis Sie bereit sind, abzurücken.

Anweisungen für Installation und Nutzung

• Installation des Zubehörs:

- Montieren Sie die PSOSchiene an der Seite des Gewehrs, um Optiken zu installieren.
- Stellen Sie sicher, dass alle Schrauben fest angezogen sind.

• Nutzung des Gewehrs:

- Laden Sie das 10SchussMagazin gemäß den Anweisungen des Herstellers.
- Überprüfen Sie vor jedem Schuss, dass das Gewehr sicher ist und keine Hindernisse im Lauf sind.
- Führen Sie eine Sicherheitsüberprüfung durch, bevor Sie das Gewehr abfeuern.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Bringen Sie das Produkt nicht in den regulären Müll.
- Informieren Sie sich über Rückgabemöglichkeiten bei Ihrem Händler oder Hersteller.

Kontaktinformationen für weitere Unterstützung

Für Sicherheitsanfragen oder weitere Informationen wenden Sie sich bitte an den Hersteller oder Ihren Händler. Achten Sie darauf, alle relevanten Informationen bereitzustellen, um eine schnelle Bearbeitung zu gewährleisten.

Bitte beachten Sie, dass diese Sicherheitshinweise sicherstellen sollen, dass Sie und andere sicher sind, während Sie das Produkt verwenden. Halten Sie sich an alle Anweisungen und Richtlinien, um die bestmögliche

Erfahrung zu gewährleisten.

Safety Instruction Guide for Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel

Introduction

Thank you for choosing the Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel. This product is designed for hunting shooting only and is not approved for sport shooting. It is essential to understand and follow the safety guidelines outlined in this manual to ensure safe and responsible use of the firearm.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Store the firearm securely and out of reach of children and unauthorized users.
- Always wear appropriate eye and ear protection when using the firearm.
- Be aware of your surroundings and ensure a clear shooting area.
- Do not use the firearm under the influence of drugs or alcohol.
- Follow all local laws and regulations regarding firearm use and ownership.
- Regularly inspect the firearm for any signs of wear or damage.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded when not in use or when being transported.
- Use only the recommended ammunition (7.62x39) for this firearm.
- Check the barrel for obstructions before loading and firing.
- Do not attempt to modify or alter the firearm in any way.
- Be cautious when handling the firearm, especially when loading and unloading.
- Do not place your finger on the trigger until you are ready to shoot.
- Use the extended safety feature to prevent accidental discharge during handling.
- Ensure that the magazine is securely attached before firing.

Instructions for Installation and Usage

Installation

1. Mounting the PSO Rail:

- Locate the PSO rail on the side of the firearm.
- Align the rail with the mounting points and secure it using the provided screws.
- Ensure that the rail is firmly attached before proceeding.

2. Attaching Optics:

- Select the appropriate optics for your needs.
- Follow the manufacturer's instructions for attaching the optics to the PSO rail.

Usage

• Loading the Magazine:

1. Ensure the firearm is on safe.
2. Insert the 10round magazine into the magazine well until it clicks into place.
3. Load the ammunition into the magazine, following the indicated direction.

- **Firing the Firearm:**

1. Check that the firearm is pointed in a safe direction.
2. Disengage the safety by moving the safety lever to the 'fire' position.
3. Take aim and gently squeeze the trigger to fire.
4. After firing, reengage the safety before handling the firearm.

- **Unloading the Firearm:**

1. Ensure the firearm is pointed in a safe direction.
2. Engage the safety.
3. Remove the magazine by pressing the extended magazine release lever.
4. Open the action and visually inspect the chamber to ensure it is empty.

Disposal Instructions

- Dispose of the firearm responsibly according to local laws and regulations.
- Do not discard the firearm in regular waste.
- Contact local authorities or a licensed firearms dealer for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further assistance regarding the Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel, please refer to your local authorized dealer or the manufacturer's website for support.

Conclusion

Following these safety instructions will help ensure a safe and enjoyable experience with your Jack 7,62x39 Holz, Extended Magazinhalter und Feuerwahlhebel. Always prioritize safety and responsibility when handling firearms.