

Mini Jack .223 Holz, Standard-Magazinhalter und Feuerwahlhebel

Attention: The weapon is not approved for sport shooting.



The weapon is approved for hunting shooting only.

- Total length: 78cm
- Barrel length: 10.19"
- Extra high quality manufacturing
- Completely civilian new production in Rogów, Poland, no surplus parts
- nitrated barrel from civilian Radom production
- Standard AK magazines fit
- Sturdy and weather resistant polymer stock
- PSO rail on side available for installation of optics
- Standard AK magazines fit
- 10-round magazine included

Attributes

- Name: Mini Jack .223 Holz, Standard-Magazinhalter und Feuerwahlhebel
- Manufacturer: WBP
- Product no.: BRD130010
- Mfr. No.: 109
- Accessory Rail: Yes
- Barrel Length: 10.19"
- Caliber: .223Rem
- Make: WBP
- Material: Wood, Steel
- Model: Mini Jack .223 Holz
- Muzzle Threads: 14x1
- Rounds: 10-Round
- Delivery weight: 3.3kg

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Mini Jack .223 Holz](#)
- [English: Mini Jack .223 Holz Safety Instruction Guide](#)

Sicherheitshinweise für die Mini Jack .223 Holz

Einleitung

Vielen Dank, dass Sie sich für die Mini Jack .223 Holz entschieden haben. Diese Anleitung bietet wichtige Sicherheitshinweise, um die sichere Verwendung des Produkts zu gewährleisten. Bitte lesen Sie diese Informationen sorgfältig durch, um Risiken zu vermeiden und die bestmögliche Nutzungserfahrung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass die Waffe nur für das jagdliche Schießen verwendet wird und nicht für das sportliche Schießen zugelassen ist.
- Bewahren Sie die Waffe außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie regelmäßig den Zustand der Waffe und der Zubehörteile.
- Verwenden Sie nur empfohlene Munition, um sicherzustellen, dass die Waffe ordnungsgemäß funktioniert.
- Halten Sie sich an alle geltenden Gesetze und Vorschriften für den Besitz und Gebrauch von Feuerwaffen in Ihrem Land.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie die Waffe niemals unter dem Einfluss von Alkohol oder Drogen.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille, während Sie die Waffe benutzen.
- Achten Sie darauf, dass der Lauf der Waffe frei von Hindernissen ist, bevor Sie abdrücken.
- Halten Sie den Abzug nicht gedrückt, während Sie die Waffe laden oder entladen.
- Zeigen Sie die Waffe niemals auf Personen oder Tiere, es sei denn, Sie sind bereit, abzudrücken.

Anweisungen für Installation und Nutzung

1. Installation der PSOSchiene:

- Stellen Sie sicher, dass die Waffe entladen ist.
- Befestigen Sie die PSOSchiene an der vorgesehenen Stelle an der Seite des Gewehrs.
- Ziehen Sie die Schrauben fest, um sicherzustellen, dass die Schiene stabil ist.

2. Laden des Magazins:

- Nehmen Sie das 10SchussMagazin aus der Waffe.
- Laden Sie die Munition in das Magazin, indem Sie sie in die vorgesehenen Fächer drücken.
- Setzen Sie das Magazin wieder in die Waffe ein, bis es einrastet.

3. Benutzung der Waffe:

- Überprüfen Sie vor jedem Schuss, ob der Lauf frei ist und keine Hindernisse vorhanden sind.
- Stellen Sie sicher, dass der Feuerwahlhebel in der richtigen Position ist, bevor Sie abdrücken.
- Schießen Sie nur in sicheren, genehmigten Bereichen und beachten Sie alle Sicherheitsvorkehrungen.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Geben Sie die Waffe nur an autorisierte Händler oder Fachleute zur Wartung oder Entsorgung weiter.

- Halten Sie sich an alle gesetzlichen Bestimmungen zur Entsorgung von Feuerwaffen und deren Zubehör.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder weitere Informationen zu Sicherheitsrichtlinien und zur Verwendung der Mini Jack .223 Holz wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler. Es ist wichtig, dass Sie sich bei Unsicherheiten oder Problemen an Fachleute wenden.

Bitte beachten Sie, dass diese Sicherheitshinweise nicht alle möglichen Risiken abdecken. Seien Sie stets vorsichtig und informiert, wenn Sie mit Feuerwaffen umgehen.

Mini Jack .223 Holz Safety Instruction Guide

Introduction

Thank you for choosing the Mini Jack .223 Holz. This guide provides important safety instructions and guidelines for the safe use of your firearm. It is essential to familiarize yourself with these instructions to ensure safe handling and operation.

General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Always wear appropriate safety gear, including eye and ear protection.
- Store the firearm in a secure place, out of reach of children and unauthorized users.
- Regularly inspect the firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- This weapon is approved for hunting shooting only and is not approved for sport shooting.
- Ensure that you are familiar with the operation of the Mini Jack .223 Holz before use.
- Use only .223 Rem ammunition with this firearm.
- Do not attempt to modify or alter the firearm in any way.
- Ensure that the safety mechanism is engaged until you are ready to fire.
- Be cautious of weather conditions that may affect your shooting experience.
- Do not use the firearm if it is damaged or malfunctioning. Seek professional assistance if necessary.
- Always check the barrel for obstructions before loading.

Instructions for Installation and Usage

1. Installation of Accessories:

- The Mini Jack .223 Holz comes with a PSO rail for the installation of optics. Ensure that any accessories are securely mounted according to the manufacturer's instructions.

2. Loading the Firearm:

- Use the included 10round magazine for loading.
- Insert the magazine into the magazine well until it clicks into place.
- Pull the charging handle to chamber a round.

3. Firing the Firearm:

- Ensure that the safety is in the "fire" position.
- Aim at your target, ensuring a clear line of sight.
- Squeeze the trigger gently to fire.

4. PostUse:

- After firing, always engage the safety mechanism before handling the firearm.
- Remove the magazine and check the chamber to ensure it is clear.
- Clean and maintain the firearm according to the manufacturer's guidelines.

Disposal Instructions

- Dispose of any unused ammunition according to local regulations.
- When disposing of the firearm, ensure it is rendered inoperable.
- Contact a licensed firearms dealer or local authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Mini Jack .223 Holz, please reach out to an EUbased contact or local firearms authority.

Please remember to regularly check for recall updates on the EU's Safety Gate platform and report any unsafe products or accidents to the appropriate authorities. Your safety and the safety of others depend on responsible firearm handling and adherence to these guidelines.