

940 JM Pro 24" Black - Mossberg 940 JM Pro 24" - Black Multicam

The Mossberg 940 JM Pro 24" Black Multicam



is a high-performance shotgun specifically designed for competition and inspired by the renowned shooter Jerry Miculek. With its precise construction and high-quality features, it delivers top-tier performance on the shooting range.

- Caliber: 12/76
- Model: 940 JM Pro Black Multicam
- Magazine Capacity: 9+1
- Barrel Length: 24"/61cm, matte black with ventilated rib
- Pre-drilled receiver for mounting rail
- Front Sight: Green fiber optic
- Synthetic Stock: Black with adjustable rubber recoil pad
- Briley Choke Extended Set (Cylinder/CYL, Improved Cylinder/IC, Modified/M)
- Overall Length: 44.75"/113.7cm
- Weight: 7.75lbs/3.519 grams
- CIP Steel Shot Proof
- Jerry Miculek Special Edition

The Mossberg 940 JM Pro 24" Black Multicam is the perfect choice for shooters seeking a reliable and accurate shotgun for competition. With its high-quality features, including the Briley Choke Extended Set and precise fiber optic front sight, it offers top-notch performance and control on the shooting range.



Attributes

- Name: Mossberg 940 JM Pro 24" - Black Multicam
- Manufacturer: MOSSBERG
- Product no.: BRD171003
- Mfr. No.: 1276-44010
- Action Type: Semi-Auto
- Caliber: 12 Gauge
- Make: Mossberg
- Model: 940 JM Pro Series
- Stock/Forearm Finish: Black Multicam
- Delivery weight: 5kg
- Shipping length: 1,300mm

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Mossberg 940 JM Pro 24" Black Multicam](#)
- [English: Safety Instruction Guide for Mossberg 940 JM Pro 24" Black Multicam](#)

Sicherheitshinweise für die Mossberg 940 JM Pro 24" Black Multicam

Einleitung

Herzlichen Glückwunsch zum Kauf der Mossberg 940 JM Pro 24" Black Multicam. Diese Hochleistungsflinte wurde speziell für den Wettbewerb entwickelt und bietet eine hervorragende Leistung. Um Ihre Sicherheit und die anderer zu gewährleisten, lesen Sie bitte diese Sicherheitsanleitung sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Verwende die Flinte nur für den vorgesehenen Zweck, um Verletzungen zu vermeiden.
- Halte die Flinte immer in einem sicheren Zustand, wenn sie nicht verwendet wird.
- Achte darauf, dass die Flinte nicht geladen ist, wenn du sie nicht aktiv benutzt.
- Bewahre die Flinte an einem sicheren Ort auf, der für Kinder unzugänglich ist.
- Verwende nur empfohlene Munition, um das Risiko von Fehlfunktionen zu minimieren.
- Prüfe die Flinte regelmäßig auf Beschädigungen oder Verschleiß.
- Halte den Abzug und die Mündung immer in eine sichere Richtung.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Trage immer Schutzbrille und Gehörschutz, wenn du mit der Flinte schießt.
- Achte darauf, dass sich keine Personen im Schussfeld befinden.
- Verwende die Flinte nicht unter dem Einfluss von Alkohol oder Drogen.
- Bei Problemen mit der Flinte, wie z.B. einer Fehlzündung, warte 30 Sekunden, bevor du die Flinte überprüfst.
- Lass die Flinte von einem qualifizierten Gunsmith überprüfen, wenn du Anzeichen von Fehlfunktionen bemerkst.

Anweisungen zur Installation und Nutzung

• Installation:

- Stelle sicher, dass die Flinte vor der Installation sicher und ungeladen ist.
- Befolge die Anweisungen im Benutzerhandbuch für die Montage der Montageschiene und das Visier.
- Überprüfe alle Verbindungen und Schrauben auf festen Sitz.

• Nutzung:

- Lade die Flinte gemäß den Anweisungen im Benutzerhandbuch.
- Stelle sicher, dass das Visier korrekt eingestellt ist, bevor du schießt.
- Übe regelmäßig, um deine Fähigkeiten zu verbessern und sicherzustellen, dass du mit der Flinte vertraut bist.

Entsorgungsanweisungen

- Entsorge die Flinte gemäß den lokalen Vorschriften für gefährliche Abfälle, wenn sie nicht mehr verwendet wird.
- Munition und andere Zubehörteile sollten ebenfalls sicher und gemäß den örtlichen Gesetzen entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Unterstützung und Informationen zu Sicherheitsanfragen wende dich bitte an den Hersteller oder einen autorisierten Händler.

Bitte beachte, dass die Einhaltung dieser Sicherheitsrichtlinien entscheidend ist, um Verletzungen und Unfälle zu vermeiden. Deine Sicherheit und die Sicherheit anderer hat oberste Priorität.

Safety Instruction Guide for Mossberg 940 JM Pro 24" Black Multicam

Introduction

Thank you for choosing the Mossberg 940 JM Pro 24" Black Multicam shotgun. This highperformance shotgun is designed for competition use and inspired by the renowned shooter Jerry Miculek. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always treat the shotgun as if it is loaded.
- Keep the shotgun pointed in a safe direction at all times.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what is beyond it.
- Use appropriate hearing and eye protection when shooting.
- Store the shotgun in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the shotgun for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the ownership and use of firearms.

Specific Safety Precautions for Use

- Ensure that the shotgun is unloaded when not in use.
- Do not use the shotgun under the influence of drugs or alcohol.
- Only use ammunition that is compatible with the 12 Gauge caliber of the shotgun.
- Be cautious of the shotgun's recoil; use the adjustable rubber recoil pad for comfort.
- Use the Briley Choke Extended Set properly to ensure safe and accurate shooting.
- Familiarize yourself with the shotgun's features, including the green fiber optic front sight, before use.

Instructions for Installation and Usage

Installation

- Ensure the shotgun is unloaded before starting the installation.
- If mounting a rail, use the predrilled receiver to securely attach the rail.
- Follow the manufacturer's instructions for any additional accessories or modifications.

Usage

- Load the magazine with a maximum capacity of 9+1 rounds.
- To load the shotgun:
 - Open the action and insert shells into the magazine.
 - Close the action to chamber a round.
- To fire the shotgun:
 - Aim at the target.
 - Ensure your finger is off the trigger until ready to shoot.
 - Squeeze the trigger gently to fire.
- After firing, follow the same procedure to unload the shotgun.

Disposal Instructions

- Dispose of the shotgun in accordance with local laws and regulations.
- If the shotgun is no longer functional, contact a qualified gunsmith for proper disposal.

- Do not dispose of ammunition in regular waste; contact local authorities for guidance on safe disposal.

Contact Information for Further Support

For any safety inquiries or concerns regarding your Mossberg 940 JM Pro 24" Black Multicam shotgun, please refer to the manufacturer's customer service resources. Always ensure that you are following the latest safety guidelines and regulations.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Mossberg 940 JM Pro 24" Black Multicam shotgun. Thank you for your attention to safety and responsible firearm use.