

VM-22 with Black Magpul Stock

VM-22 with Black Magpul Stock



The VM-22 Rifle features a Superlite Barreled Action fitted to a Magpul X-22 Hunter Stock. This combination makes for an incredibly well balanced rifle suited for offhand or benchrest shooting.

This combination is not only extremely accurate but also a very lightweight, versatile rifle.

- 1 Magazine 10 Round
- Black receiver is Type III hard anodized
- 1/2 x 28 threaded muzzle
- Aluminum Forward Blow Compensator included (compensator is removable)
- Adjustable LOP from 12.5"-14.5" with 0.50" Spacers
- Black receiver is Type III hard anodized
- Receiver features threaded in barrel
- Integral Picatinny rail

Attributes

- Name: VM-22 with Black Magpul Stock
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231056
- Mfr. No.: VC22RM-B
- Barrel Length: 17"
- Caliber: .22lr
- Capacity: 10-Round
- Color: Black
- Elevation: 20 MOA
- Length: 36.75"
- Length Of Pull: 12.5" - 14.5"
- Make: Volquartsen
- Material: Aluminum, Carbon
- Model: VM-22
- Muzzle Threads: 1/2-28
- Twist Rate: 1-16
- Delivery weight: 3kg
- UPC: 810162017101

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den VOLQUARTSEN VM22 mit schwarzem Magpul Stock](#)
- [English: Safety Instruction Guide for the VOLQUARTSEN VM22 with Black Magpul Stock](#)

Sicherheitshinweise für den VOLQUARTSEN VM22 mit schwarzem Magpul Stock

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des VOLQUARTSEN VM22 mit schwarzem Magpul Stock. Dieses Gewehr ist darauf ausgelegt, Ihnen ein sicheres und angenehmes Schießerlebnis zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und verantwortungsbewusst verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass Sie die Bedienungsanleitung vollständig gelesen und verstanden haben, bevor Sie das Gewehr verwenden.
- Verwenden Sie das Gewehr niemals unter dem Einfluss von Alkohol oder Drogen.
- Halten Sie das Gewehr immer in einem sicheren Zustand, bis Sie bereit sind, zu schießen.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck, nämlich das Schießen mit .22lr Munition.
- Achten Sie darauf, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Lagern Sie das Gewehr an einem sicheren Ort, der für Kinder unzugänglich ist.
- Überprüfen Sie regelmäßig den Zustand des Gewehrs und der Munition.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Tragen Sie immer Schutzbrille und Ohrenschützer, wenn Sie das Gewehr verwenden.
- Stellen Sie sicher, dass der Lauf des Gewehrs frei von Obstruktionen ist, bevor Sie schießen.
- Verwenden Sie nur die empfohlene Munition für das Gewehr (.22lr).
- Achten Sie darauf, dass das Gewehr immer in einem sicheren Zustand ist, wenn es nicht verwendet wird.
- Halten Sie Ihren Finger vom Abzug, bis Sie bereit sind zu schießen.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, insbesondere in der Nähe von Kindern oder unerfahrenen Benutzern.

Anweisungen für Installation und Nutzung

• Installation des Gewehrs:

- Stellen Sie sicher, dass das Gewehr auf einer stabilen Oberfläche platziert ist.
- Überprüfen Sie, ob alle Teile korrekt montiert sind und ob keine sichtbaren Mängel vorhanden sind.

• Nutzung des Gewehrs:

- Laden Sie das Magazin mit bis zu 10 Schuss .22lr Munition.
- Setzen Sie das Magazin vorsichtig in den Gewehr magazin Schacht ein, bis es einrastet.
- Stellen Sie die LOP (Length Of Pull) auf die gewünschte Länge von 12.5" bis 14.5" ein.
- Führen Sie eine Sicherheitsüberprüfung durch, um sicherzustellen, dass sich keine Munition im Lauf befindet, bevor Sie das Gewehr aktiv verwenden.
- Zielen Sie auf die gewünschte Zielscheibe und drücken Sie den Abzug sanft, um den Schuss abzugeben.

Entsorgungsanweisungen

- Entsorgen Sie leere oder defekte Munition gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Lagern Sie das Gewehr in einem geeigneten Gewehrschrank oder einer sicheren Aufbewahrungseinheit, wenn es nicht in Gebrauch ist.

- Wenn Sie das Gewehr nicht mehr benötigen, wenden Sie sich an einen autorisierten Händler oder Waffenexperten zur sicheren Entsorgung.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung wenden Sie sich bitte an den Hersteller oder autorisierte Händler. Sie können auch die EU Safety Gate-Plattform besuchen, um Informationen über Rückrufe und Sicherheitswarnungen zu erhalten.

Schlussfolgerung

Die Sicherheit hat oberste Priorität. Indem Sie diese Richtlinien befolgen, tragen Sie dazu bei, ein sicheres Schießerlebnis zu gewährleisten. Vielen Dank, dass Sie sich für den VOLQUARTSEN VM22 entschieden haben. Genießen Sie Ihr Schießerlebnis und bleiben Sie sicher!

Safety Instruction Guide for the VOLQUARTSEN VM22 with Black Magpul Stock

Introduction

Thank you for choosing the VOLQUARTSEN VM22 with Black Magpul Stock. This guide provides essential safety instructions and guidelines to ensure the safe use of your rifle. It is important to read and understand these instructions before using the product to minimize risks and enhance your shooting experience.

General Safety Guidelines

- Always treat your rifle as if it is loaded.
- Keep the muzzle pointed in a safe direction at all times.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Only use ammunition specified for this rifle (.22lr).
- Wear appropriate safety gear, including eye and ear protection, when using the rifle.
- Be aware of your surroundings and ensure a clear shooting area.
- Do not use the rifle under the influence of drugs or alcohol.
- Regularly inspect your rifle for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Ensure that the magazine is removed and the chamber is empty before handling the rifle.
- Never place your finger on the trigger until you are ready to shoot.
- Avoid distractions while handling or shooting the rifle.
- Do not modify the rifle or use any unauthorized accessories.
- Be cautious of ricochets and ensure you have a proper backstop when shooting.
- If a misfire occurs, keep the rifle pointed downrange for at least 30 seconds before attempting to clear the malfunction.
- Always ensure that the safety mechanism is engaged when the rifle is not in use.

Instructions for Installation and Usage

1. Installation of Accessories

- Ensure that the rifle is unloaded before installing any accessories.
- Follow the manufacturer's instructions for any additional accessories you may wish to install.

2. Loading the Rifle

- Insert the magazine into the rifle until it clicks into place.
- Pull back the bolt to chamber a round.
- Ensure that the safety is disengaged before firing.

3. Firing the Rifle

- Assume a stable shooting position.
- Aim at your target and ensure that the area is clear.
- Gently squeeze the trigger to fire.

4. PostUse Care

- After use, clean the rifle according to the manufacturer's instructions.
- Store the rifle in a secure location.

Disposal Instructions

- Dispose of the rifle in accordance with local laws and regulations.
- If the rifle is damaged beyond repair, contact a licensed firearm dealer for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding your VOLQUARTSEN VM22, please contact the manufacturer or your local dealer.

Conclusion

Following these safety instructions will help ensure a safe and enjoyable experience with your VOLQUARTSEN VM22. Always prioritize safety and responsibility when handling firearms. Thank you for your attention to these guidelines.