

Accurizing Kit, MKII or MKIII, Gold Trigger - Accurizing Kit, MKII or MKIII, Gold Target Trigger

Accurizing Kit, MKII or MKIII, Gold Trigger



Complete drop-in kit comes complete with Target Hammer, Target Sear, Target Trigger, Extended Bolt Release and Trigger Return Spring with Polished Plunger. The trigger features adjustable pretravel and overtravel screws.

The Accurizing Kit combines all of the internal components needed for that crisp, clean 2.25lb trigger pull the discriminating shooter is looking for. No stoning or fitting required. Final trigger pull may vary slightly due to factory frame variances.

- Note: Use of the included Hammer Bushing in MKIII pistols will remove the magazine disconnect feature from your pistol.
- Accurizing Kits fit the Ruger MKII, MKIII and all variations of the MKIII 22/45 (extended bolt release and sear spring are not used when installing in a 22/45).
- This kit also includes a Volquartsen MKII Hammer Bushing that must be used when eliminating the magazine disconnect feature in the Ruger MKIII. Please note the only way we recommend to remove the magazine disconnect in the Ruger MKIII is by using this kit.

Attributes

- Name: Accurizing Kit, MKII or MKIII, Gold Target Trigger
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231060
- Mfr. No.: VC2AK-GT
- Color: Gold
- Make: Ruger
- Model: MKII, MKIII
- Weight: 2.25 lbs
- Delivery weight: 0.3kg
- UPC: 810162019570

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das Accurizing Kit, MKII oder MKIII, Gold Trigger](#)
- [English: Accurizing Kit Safety Instructions](#)

Sicherheitshinweise für das Accurizing Kit, MKII oder MKIII, Gold Trigger

Einleitung

Vielen Dank, dass Sie sich für das Accurizing Kit, MKII oder MKIII, Gold Trigger entschieden haben. Dieses Kit wurde entwickelt, um Ihnen eine verbesserte Leistung und Genauigkeit zu bieten. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Das Produkt ist nur für den vorgesehenen Gebrauch bestimmt. Verwenden Sie es nicht für andere Zwecke.
- Stellen Sie sicher, dass das Produkt vor der Verwendung in einwandfreiem Zustand ist.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und schutzbedürftigen Personen.
- Überprüfen Sie regelmäßig auf mögliche Beschädigungen oder Abnutzungserscheinungen.
- Melden Sie unsichere Produkte oder Vorfälle an die zuständigen Behörden.
- Informieren Sie sich über Rückrufaktionen auf der EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das Kit nur mit kompatiblen Pistolen (Ruger MKII, MKIII und MKIII 22/45).
- Beachten Sie, dass die Verwendung der mitgelieferten Hammerbuchse in MKIIIPistolen die Magazintrennfunktion entfernt.
- Überprüfen Sie die Einstellungen des Abzugs vor der Nutzung. Der Abzug kann aufgrund von Abweichungen des Werksrahmens variieren.
- Stellen Sie sicher, dass Sie den Abzug nicht über die empfohlenen Spezifikationen hinaus anpassen.
- Achten Sie darauf, dass Sie beim Einbau des Kits die Anweisungen genau befolgen, um Verletzungen zu vermeiden.

Anleitungen für Installation und Nutzung

1. Vorbereitung

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie mit der Installation beginnen.
- Legen Sie alle Teile des Kits auf eine saubere und organisierte Arbeitsfläche.

2. Installation

- Entfernen Sie den vorhandenen Abzug und die internen Komponenten gemäß den Anweisungen im Handbuch Ihrer Pistole.
- Setzen Sie die neuen Komponenten des Accurizing Kits ein:
 - TargetHammer
 - TargetSear
 - TargetAbzug
 - Verlängerter Bolzenauslöser
 - Abzugsrückholfeder
- Achten Sie darauf, die einstellbaren Schrauben für Vor und Nachlauf korrekt einzustellen.

3. Nach der Installation

- Überprüfen Sie die Funktionalität des Abzugs, um sicherzustellen, dass er ordnungsgemäß funktioniert.

- Testen Sie die Waffe immer an einem sicheren Ort, um sicherzustellen, dass alle Funktionen wie vorgesehen arbeiten.

Entsorgungsanweisungen

- Entsorgen Sie alle Verpackungsmaterialien und nicht verwendeten Teile gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Stellen Sie sicher, dass alle Teile, die nicht mehr benötigt werden, sicher und umweltgerecht entsorgt werden.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung bezüglich des Accurizing Kits, MKII oder MKIII, Gold Trigger, wenden Sie sich bitte an den Hersteller oder einen autorisierten Fachhändler.

Accurizing Kit Safety Instructions

Introduction

Thank you for choosing the Accurizing Kit, MKII or MKIII, Gold Trigger. This guide provides essential safety instructions and guidelines to ensure safe and effective use of the product. Please read this document carefully before installation and use.

General Safety Guidelines

- Always ensure that the firearm is unloaded before beginning any installation or maintenance.
- Keep the Accurizing Kit and all its components out of reach of children and unauthorized users.
- Use the Accurizing Kit only with compatible models: Ruger MKII, MKIII, and all variations of the MKIII 22/45.
- Be aware that improper installation may lead to unsafe firearm operation.
- Regularly inspect the firearm and components for wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that you are familiar with your firearm's manual and operation.
- Use protective eyewear when handling or modifying firearms.
- Never attempt to modify or install components while the firearm is loaded.
- Follow all local laws and regulations regarding firearm modifications.
- If you experience any malfunction or unusual behavior from your firearm after installation, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools (e.g., screwdriver, pliers) for installation.

2. Installation Steps:

- Remove the existing trigger, hammer, and sear from the firearm according to the manufacturer's instructions.
- Install the Target Hammer, Target Sear, and Target Trigger from the Accurizing Kit.
- Attach the Extended Bolt Release and Trigger Return Spring with Polished Plunger.
- Adjust the pretravel and overtravel screws to achieve the desired trigger feel.
- Ensure all components are securely in place and function correctly.

3. Final Checks:

- Conduct a function test with the firearm unloaded to ensure the trigger operates smoothly.
- Verify that the magazine disconnect feature is functioning as intended if the Hammer Bushing is not used.

4. Usage:

- When using the firearm, always follow the basic rules of firearm safety:
 - Treat every firearm as if it is loaded.

- Never point the firearm at anything you do not intend to shoot.
- Keep your finger off the trigger until you are ready to shoot.
- Be sure of your target and what is beyond it.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If you need to dispose of the Accurizing Kit or its components, contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any inquiries or support related to the Accurizing Kit, please refer to the product documentation or contact the manufacturer directly.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Accurizing Kit. Thank you for your attention to safety.