

VF Target Frame, Target 22 Style, Black

VF Target Frame, Target 22 Style, Black



The VF Target Frame is CNC-machined from billet aluminum. It is a complete frame with the following features: Accurizing Kit (includes Extended Bolt Release, CNC-machined Target Trigger, wire EDM-cut Target Hammer and Target Sear), CNC-Machined Disconnect, and Extended Safety.

The VF Target Frame is shipped with a clean, crisp 2.25 lb trigger pull. No magazine disconnect is included with this frame.

Attributes

- Name: VF Target Frame, Target 22 Style, Black
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231088
- Mfr. No.: VC3NF-B
- Color: Black
- Make: Ruger
- Material: Anodized Aluminum
- Model: MKIII Target 22 Style
- Delivery weight: 0.24kg
- UPC: 810162013134

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den VF Target Frame, Target 22 Style, Black](#)
- [English: VF Target Frame Safety Instruction Guide](#)

Sicherheitshinweise für den VF Target Frame, Target 22 Style, Black

Einführung

Herzlichen Glückwunsch zum Kauf des VF Target Frame, Target 22 Style, Black. Dieser Rahmen wurde aus hochwertigem, CNCgefrästem Aluminium gefertigt und bietet Ihnen eine präzise Grundlage für Ihre Schießaktivitäten. Um sicherzustellen, dass Sie das Produkt sicher und effektiv nutzen, lesen Sie bitte diese Sicherheitshinweise sorgfältig durch.

Allgemeine Sicherheitsrichtlinien

- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie den Rahmen und alle Zubehörteile außerhalb der Reichweite von Kindern.
- Überprüfen Sie regelmäßig, ob der Rahmen und alle Teile in einwandfreiem Zustand sind.
- Melden Sie unsichere Produkte oder Vorfälle umgehend den zuständigen Behörden.
- Informieren Sie sich über Rückrufaktualisierungen auf der EU Safety Gate Plattform.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Stellen Sie sicher, dass der Rahmen vor der Verwendung korrekt installiert ist.
- Verwenden Sie nur empfohlene Zubehörteile und Ersatzteile.
- Achten Sie darauf, dass keine Fremdkörper in den Mechanismus gelangen.
- Verwenden Sie den Abzug niemals, wenn Sie nicht bereit sind zu schießen.
- Achten Sie beim Umgang mit dem Rahmen stets auf Ihre Umgebung.

Anweisungen zur Installation und Nutzung

Installation

1. **Überprüfen Sie den Lieferumfang:** Stellen Sie sicher, dass alle Teile, einschließlich Accurizing Kit, CNCgefrästen Disconnecter und Extended Safety, enthalten sind.
2. **Montage des Rahmens:**
 - Befestigen Sie den Rahmen gemäß der Anleitung des Herstellers.
 - Stellen Sie sicher, dass alle Schrauben fest angezogen sind.
3. **Überprüfung der Sicherheitsmechanismen:**
 - Testen Sie den Extended Safety, um sicherzustellen, dass er ordnungsgemäß funktioniert.
 - Überprüfen Sie den Abzug auf seine Funktionalität.

Nutzung

- Halten Sie den Rahmen immer in einer sicheren Richtung.
- Stellen Sie sicher, dass der Abzug nicht versehentlich betätigt wird.
- Verwenden Sie den Rahmen nur in dafür vorgesehenen Schießständen.
- Achten Sie darauf, dass alle Sicherheitsvorkehrungen während des Schießens beachtet werden.

Entsorgungsanweisungen

- Entsorgen Sie den Rahmen und alle Zubehörteile gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Stellen Sie sicher, dass keine Teile in die Umwelt gelangen, die schädlich sein könnten.
- Informieren Sie sich über Recyclingmöglichkeiten für Metall und andere Materialien.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder bei Fragen zu diesem Produkt wenden Sie sich bitte an den Hersteller oder einen autorisierten Händler.

VF Target Frame Safety Instruction Guide

Introduction

Thank you for choosing the VF Target Frame, Target 22 Style, Black. This guide provides essential safety instructions to ensure the safe use and handling of your product. Please read this document carefully before using the VF Target Frame.

General Safety Guidelines

- Ensure the VF Target Frame is used only for its intended purpose.
- Always handle the frame with care to prevent accidental discharge.
- Keep the frame out of reach of children and unauthorized users.
- Regularly inspect the frame for any signs of wear or damage before use.
- Store the frame in a secure location when not in use.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate eye and ear protection when using the VF Target Frame.
- Ensure the area is clear of bystanders before firing.
- Never point the frame at anything you do not intend to shoot.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your surroundings and ensure a safe backdrop before firing.
- Do not modify the frame in any way that may affect its safety or performance.
- Follow all local laws and regulations regarding firearm use and ownership.

Instructions for Installation and Usage

Installation

1. **Unboxing:** Carefully remove the VF Target Frame from its packaging. Ensure all components are present.
2. **Assembly:** If applicable, follow these steps for assembly:
 - Attach the Extended Bolt Release.
 - Install the CNCmachined Target Trigger.
 - Insert the wire EDMcut Target Hammer and Target Sear.
 - Install the CNCmachined Disconnecter and Extended Safety.
3. **Inspection:** After assembly, check all components to ensure they are securely attached and functioning correctly.

Usage

1. **Loading:** Ensure the frame is pointed in a safe direction. Load the magazine according to the manufacturer's instructions.
2. **Firing:**
 - Ensure the safety is engaged until you are ready to fire.
 - Disengage the safety and take aim.
 - Gently squeeze the trigger to fire.
 - After firing, engage the safety immediately.
3. **Cleaning:** After use, clean the frame following the manufacturer's recommendations to maintain performance and safety.

Disposal Instructions

- Dispose of the VF Target Frame in accordance with local regulations.
- If the frame is no longer functional, consider recycling materials where possible.
- Do not dispose of the frame in regular household waste.

Contact Information for Further Support

For any safety inquiries or support regarding the VF Target Frame, please contact your local authorized dealer or the manufacturer directly. Ensure you have your product details available for reference.

Thank you for prioritizing safety when using the VF Target Frame. By following these guidelines, you can help ensure a safe and enjoyable experience.