

Extended Bolt Release for Ruger MK IV 22/45, Black

The extended bolt release gives you more surface area and deep grooves for easy thumb engagement.



The bolt release pad is CNC machined from 416 stainless steel and extends .050" further than the original release. This .050" extension combined with the improved ergonomic, low profile design of this release is an improvement every shooter is looking for.

Attributes

- Name: Extended Bolt Release for Ruger MK IV 22/45, Black
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231149
- Mfr. No.: VC4SR-45-B
- Make: Ruger
- Model: Mark IV 22/45
- Delivery weight: 0.1kg
- UPC: 810162019501

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Extended Bolt Release für Ruger MK IV 22/45](#)
- [English: Extended Bolt Release for Ruger MK IV 22/45 Safety Instruction Guide](#)

Sicherheitshinweise für den Extended Bolt Release für Ruger MK IV 22/45

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des VOLQUARTSEN Extended Bolt Release für Ruger MK IV 22/45. Dieses Produkt wurde entwickelt, um die Bedienung Ihres Feuerwaffenmodells zu verbessern. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um sicherzustellen, dass Sie das Produkt sicher und effektiv verwenden.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für den vorgesehenen Zweck verwendet wird.
- Bewahren Sie das Produkt außerhalb der Reichweite von Kindern auf.
- Überprüfen Sie das Produkt regelmäßig auf Anzeichen von Beschädigungen oder Verschleiß.
- Verwenden Sie das Produkt niemals, wenn es beschädigt ist.
- Halten Sie sich an alle geltenden Gesetze und Vorschriften in Ihrem Land oder Ihrer Region.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Achten Sie darauf, dass der Bolt Release während der Verwendung nicht blockiert ist.
- Verwenden Sie nur die empfohlenen Werkzeuge und Techniken für die Installation.
- Tragen Sie beim Umgang mit der Waffe stets geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Seien Sie sich der Umgebung bewusst und stellen Sie sicher, dass sich keine unbefugten Personen in der Nähe befinden.
- Halten Sie die Waffe immer in einer sicheren Position, wenn Sie den Bolt Release verwenden.

Anweisungen zur Installation und Nutzung

Installation

1. **Werkzeuge vorbereiten:** Stellen Sie sicher, dass Sie die notwendigen Werkzeuge zur Hand haben, einschließlich eines Schraubendrehers.
2. **Sicherheit prüfen:** Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie mit der Installation beginnen.
3. **Alten Bolt Release entfernen:** Entfernen Sie vorsichtig den Original Bolt Release gemäß den Anweisungen des Herstellers.
4. **Neuen Bolt Release einsetzen:** Setzen Sie den VOLQUARTSEN Extended Bolt Release in die vorgesehene Position ein.
5. **Befestigen:** Ziehen Sie die Schrauben gleichmäßig fest, um sicherzustellen, dass der Bolt Release sicher sitzt.
6. **Funktionsprüfung:** Überprüfen Sie die Funktion des neuen Bolt Release, um sicherzustellen, dass er ordnungsgemäß funktioniert.

Nutzung

- Um den Bolt Release zu betätigen, drücken Sie mit dem Daumen auf die verlängerte Fläche.
- Achten Sie darauf, dass Ihre Finger immer außerhalb des Abzugsbereichs sind, um versehentliche Schüsse zu vermeiden.
- Üben Sie den Umgang mit dem Bolt Release in einer sicheren Umgebung, bevor Sie ihn unter realen Bedingungen verwenden.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt gemäß den örtlichen Vorschriften für Elektroschrott oder Metallabfälle.
- Vermeiden Sie die Entsorgung in regulären Haushaltsmüll.
- Informieren Sie sich über Recyclingmöglichkeiten in Ihrer Nähe.

Kontaktinformation für weitere Unterstützung

Für Fragen oder weitere Informationen zu diesem Produkt wenden Sie sich bitte an den Hersteller oder den Verkaufsstellen, bei denen das Produkt erworben wurde. Sie sollten in der Lage sein, Ihnen die benötigten Informationen bereitzustellen.

Schlussfolgerung

Die Sicherheit und Zufriedenheit des Verbrauchers stehen an erster Stelle. Indem Sie diese Sicherheitsrichtlinien befolgen, tragen Sie dazu bei, dass Ihr Erlebnis mit dem VOLQUARTSEN Extended Bolt Release für Ruger MK IV 22/45 sicher und angenehm ist.

Extended Bolt Release for Ruger MK IV 22/45

Safety Instruction Guide

Introduction

Thank you for purchasing the Extended Bolt Release for Ruger MK IV 22/45. This guide provides essential safety instructions to ensure the safe and effective use of your new product. Please read this document carefully before installation and use.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following guidelines:

- Always handle firearms with care and respect.
- Ensure the firearm is unloaded before installing or handling the bolt release.
- Store the product in a safe place, out of reach of children and unauthorized users.
- Regularly inspect your firearm and accessories for wear and damage.
- Follow all local laws and regulations regarding firearm modifications and usage.
- Be aware of your surroundings and ensure a safe environment when using your firearm.

Specific Safety Precautions for Use

When using the Extended Bolt Release, please observe the following precautions:

- Do not use the bolt release if it appears damaged or malfunctioning.
- Ensure that your hands are dry and clean when engaging the bolt release to prevent slipping.
- Avoid applying excessive force when using the bolt release to prevent injury or damage.
- Always wear appropriate eye and ear protection when operating your firearm.
- Keep fingers away from the trigger until you are ready to shoot.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure the firearm is unloaded and pointed in a safe direction.
2. **Remove the Original Bolt Release:**
 - Use appropriate tools to carefully remove the original bolt release from the firearm.
 - Follow the manufacturer's instructions for disassembly if necessary.
3. **Install the Extended Bolt Release:**
 - Align the Extended Bolt Release with the mounting area.
 - Securely attach the bolt release, ensuring it is properly seated and fastened.
4. **Test the Installation:**
 - After installation, perform a function check to ensure the bolt release operates correctly.
 - Ensure there are no obstructions that could interfere with its operation.

Usage

- To engage the bolt release, use your thumb to press down on the extended pad.
- Ensure that the firearm is in a safe condition before engaging the bolt release.
- Familiarize yourself with the feel and operation of the extended bolt release to ensure smooth usage.

Disposal Instructions

When disposing of the Extended Bolt Release or any related components, please follow these guidelines:

- Do not dispose of the product in regular household waste.
- Check local regulations for proper disposal methods for metal components.
- Consider recycling the product if possible to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the Extended Bolt Release, please refer to the manufacturer's contact information provided with your product. Ensure you have your purchase details ready when seeking assistance.

Conclusion

By following these safety instructions, you can ensure the safe use of the Extended Bolt Release for Ruger MK IV 22/45. Your safety and the safety of those around you are of utmost importance. Thank you for choosing this product, and enjoy your enhanced shooting experience.