

Summit Rifle, 22 LR, Barreled Action Only

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,



Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR, Barreled Action Only
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231155
- Mfr. No.: VCB-LR-BA
- Barrel Finish: Carbon
- Caliber: .22lr
- Elevation: 20 MOA
- Make: Ruger
- Material: Anodized Aluminum
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 1.8kg
- UPC: 810162019204

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das Summit Rifle, 22 LR, Barreled Action Only](#)
- [English: Safety Instruction Guide for the Summit Rifle, 22 LR, Barreled Action Only](#)

Sicherheitshinweise für das Summit Rifle, 22 LR, Barreled Action Only

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des Volquartsen Summit Repetierbüchse, einem innovativen Gewehr, das für Wettkampfschießen und Niederwildjagd entwickelt wurde. Um die Sicherheit während der Nutzung zu gewährleisten, ist es wichtig, diese Sicherheitshinweise sorgfältig zu lesen und zu befolgen.

Allgemeine Sicherheitsrichtlinien

- Achten Sie darauf, dass das Gewehr immer als geladen betrachtet wird, bis Sie sicher sind, dass es entladen ist.
- Halten Sie den Lauf stets in eine sichere Richtung, auch wenn das Gewehr nicht verwendet wird.
- Verwenden Sie das Gewehr nur für den vorgesehenen Zweck und in Übereinstimmung mit den geltenden Gesetzen.
- Bewahren Sie das Gewehr außerhalb der Reichweite von Kindern und unbefugten Personen auf.
- Überprüfen Sie regelmäßig den Zustand des Gewehrs und führen Sie Wartungsarbeiten gemäß den Anweisungen durch.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie nur die vom Hersteller empfohlenen Munitionstypen.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.
- Stellen Sie sicher, dass der Schießstand sicher und für das Schießen geeignet ist.
- Informieren Sie sich über die Umgebung, bevor Sie das Gewehr abfeuern, und achten Sie auf mögliche Gefahren.
- Lassen Sie das Gewehr niemals unbeaufsichtigt, wenn es geladen ist.

Anweisungen für Installation und Nutzung

- **Installation:**
 - Überprüfen Sie vor der Installation, dass alle Teile des Gewehrs vorhanden sind und keine sichtbaren Schäden aufweisen.
 - Befolgen Sie die Montageanleitungen des Herstellers, um sicherzustellen, dass alle Komponenten korrekt installiert sind.
- **Nutzung:**
 - Laden Sie das Gewehr gemäß den Anweisungen des Herstellers.
 - Stellen Sie sicher, dass der Sicherheitsmechanismus aktiviert ist, bevor Sie das Gewehr handhaben.
 - Überprüfen Sie vor jedem Schuss die Munition und den Zustand des Gewehrs.
 - Nach dem Schießen entladen Sie das Gewehr und reinigen Sie es gemäß den Wartungsanweisungen.

Entsorgungsanweisungen

- Entsorgen Sie leere Munition und andere Abfälle gemäß den örtlichen Vorschriften für gefährliche Abfälle.
- Stellen Sie sicher, dass das Gewehr nicht mehr funktionsfähig ist, bevor Sie es entsorgen oder verkaufen.
- Informieren Sie sich über die umweltgerechte Entsorgung von Waffen und Munition in Ihrer Region.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken zur Sicherheit Ihres Volquartsen Summit Repetierbüchse wenden Sie sich bitte an den Hersteller oder Ihren Händler. Achten Sie darauf, alle relevanten Informationen über das Produkt bereitzuhalten, wenn Sie Unterstützung anfordern.

Bitte beachten Sie, dass die Nichteinhaltung dieser Sicherheitsrichtlinien zu schweren Verletzungen oder sogar zum Tod führen kann. Ihre Sicherheit und die Sicherheit anderer hat oberste Priorität.

Safety Instruction Guide for the Summit Rifle, 22 LR, Barreled Action Only

Introduction

Thank you for choosing the Summit Rifle, 22 LR, Barreled Action Only by Volquartsen. This guide provides essential safety instructions to ensure the safe use of your rifle. Please read and understand all safety guidelines and instructions before using the product. Adhering to these guidelines will help you avoid potential hazards and enjoy your shooting experience.

General Safety Guidelines

- Always treat the rifle as if it is loaded, even when you believe it is not.
- Keep the rifle pointed in a safe direction at all times.
- Only load the rifle when you are ready to shoot.
- Ensure the safety is engaged until you are ready to fire.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Use appropriate eye and ear protection while shooting.
- Store the rifle in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the rifle for any signs of damage or wear before use.
- Follow all local laws and regulations regarding firearm use and ownership.

Specific Safety Precautions for Use

- Ensure you are of legal age to possess and operate a firearm in your jurisdiction.
- Do not use the rifle under the influence of alcohol, drugs, or any substances that may impair your judgment.
- Only use ammunition that is specified for the Summit Rifle, .22 LR.
- Be cautious of environmental conditions, such as wind and lighting, that may affect shooting safety.
- Always inform others in the vicinity when you are about to shoot.
- Do not attempt to modify or alter the rifle in any way.
- If the rifle fails to fire, keep the muzzle pointed downrange and wait at least 30 seconds before attempting to clear the malfunction.

Instructions for Installation and Usage

Installation

1. **Unboxing:** Carefully remove the rifle from the packaging. Inspect all components for damage.
2. **Mounting Accessories:** If you plan to mount a scope or other accessories, ensure they are compatible with the 20 MOA Picatinny Rail.
3. **Loading the Magazine:** Insert the .22 LR ammunition into the 10round magazine. Ensure that the rounds are seated properly.
4. **Inserting the Magazine:** Insert the loaded magazine into the rifle until it clicks into place.
5. **Chambering a Round:** Pull the bolt back fully and release it to chamber a round. Ensure the safety is engaged during this process.

Usage

1. **Setting Up for Shooting:** Find a safe and appropriate shooting range or area. Ensure you have a clear line of sight and a safe backdrop.
2. **Aiming:** Use proper shooting stance and grip. Align your sights with the target.
3. **Firing:** When ready, disengage the safety and gently squeeze the trigger to fire.

4. **After Shooting:** Once you have finished shooting, engage the safety, remove the magazine, and clear the chamber by pulling the bolt back and visually inspecting it.

Disposal Instructions

When disposing of the Summit Rifle or its components, follow these guidelines:

- Do not dispose of the rifle in regular household waste.
- Contact local authorities or a licensed firearms dealer for safe disposal options.
- Ensure all ammunition is used or disposed of in accordance with local regulations.

Contact Information for Further Support

For any inquiries regarding safety, usage, or support, please refer to the manufacturer's contact information included in the product packaging or your purchase receipt.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Summit Rifle, 22 LR, Barreled Action Only. Always prioritize safety and responsibility in all aspects of firearm use. Thank you for your attention to these important guidelines.