

Summit Rifle, 22 LR Magpul Stock - Summit Rifle, 22 LR, OD Green Magpul Stock

The Volquartsen Summit bolt action is based on a concept originally developed by Primary Weapons Systems. The Volquartsen Summit represents the combination of their innovative design and 40+ years of our own rimfire experience,



Designed for both competition shooting as well as small game hunting, this unique rifle is a straight-pull bolt action inspired by the 10/22 style platform. The CNC-machined receiver features an integral 20 MOA Picatinny Rail, making it the perfect rifle for any rimfire long range shooting.

This innovative design is built for everyone from the junior just getting into shooting to the accomplished competitor. It features everything you could ask for.

Attributes

- Name: Summit Rifle, 22 LR, OD Green Magpul Stock
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231159
- Mfr. No.: VCB-LR-OD
- Action Type: Bolt Action
- Barrel Finish: Carbon
- Caliber: .22lr
- Color: O.D. Green
- Length Of Pull: 12.5" - 14.5"
- Make: Ruger
- Model: Summit
- Muzzle Threads: 1/2-28
- Rounds: 10-Round
- Twist Rate: 1-16
- Delivery weight: 2.7kg
- UPC: 810162017392

Item details

EU Export Disabled

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für die Volquartsen Summit Repetierbüchse](#)
- [English: Safety Instruction Guide for Summit Rifle, 22 LR Magpul Stock O.D. Green](#)

Sicherheitshinweise für die Volquartsen Summit Repetierbüchse

Einleitung

Herzlichen Glückwunsch zum Kauf Ihrer Volquartsen Summit Repetierbüchse. Diese Anleitung bietet wichtige Informationen zur sicheren Verwendung des Produkts, um sicherzustellen, dass Sie die bestmögliche Erfahrung haben. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, bevor Sie das Gewehr verwenden.

Allgemeine Sicherheitsrichtlinien

- Halte das Gewehr immer in einem sicheren Zustand. Behandle jede Waffe so, als wäre sie geladen.
- Verwende das Gewehr nur für den vorgesehenen Zweck. In diesem Fall ist es für Wettkampfschießen und Niederwildjagd gedacht.
- Bewahre das Gewehr an einem sicheren Ort auf, außerhalb der Reichweite von Kindern und unbefugten Personen.
- Überprüfe vor jeder Benutzung das Gewehr auf mögliche Mängel oder Schäden.
- Trage immer geeignete Schutzausrüstung, einschließlich Gehörschutz und Schutzbrille.

Besondere Sicherheitsvorkehrungen für die Nutzung

- Achte darauf, dass du in einem sicheren und genehmigten Bereich schießt.
- Verwende nur die empfohlenen Munitionstypen (.22 LR) für die Summit Repetierbüchse.
- Halte den Finger immer vom Abzug, bis du bereit bist zu schießen.
- Achte darauf, dass sich keine Personen oder Tiere im Schussfeld befinden.
- Bei Fehlzündungen oder anderen Problemen, warte mindestens 30 Sekunden, bevor du den Verschluss öffnest.

Anweisungen zur Installation und Nutzung

• Installation:

- Stelle sicher, dass das Gewehr vor der Montage in einem sicheren Zustand ist.
- Montiere das Gewehr gemäß den Anweisungen des Herstellers. Verwende die integrierte 20 MOA PicatinnySchiene für Zubehör.

• Nutzung:

- Lade das Gewehr gemäß den Anweisungen des Herstellers.
- Stelle sicher, dass das Gewehr sicher positioniert ist, bevor du schießt.
- Betätige den Abzug sanft, um ein ungewolltes Auslösen zu vermeiden.
- Nach dem Schießen, entlade das Gewehr sofort und überprüfe, ob es leer ist.

Entsorgungsanweisungen

- Entsorge die Waffe gemäß den örtlichen Gesetzen und Vorschriften.
- Informiere dich über die richtigen Verfahren zur Entsorgung von Munition und anderen gefährlichen Materialien.
- Vermeide es, das Gewehr oder Munition in den regulären Müll zu werfen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Bedenken zur Sicherheit oder Nutzung des Produkts, wende dich bitte an den Hersteller oder einen autorisierten Fachhändler. Achte darauf, dass alle Anfragen zur Sicherheit in der EU an einen EUbasierten Kontakt gerichtet werden.

Schlussfolgerung

Die Sicherheit hat oberste Priorität. Durch die Beachtung dieser Anweisungen und Sicherheitsrichtlinien kannst du sicherstellen, dass deine Erfahrung mit der Volquartsen Summit Repetierbüchse sowohl sicher als auch angenehm ist. Halte dich stets an die geltenden Gesetze und Vorschriften in deinem Land oder deiner Region.

Safety Instruction Guide for Summit Rifle, 22 LR Magpul Stock O.D. Green

Introduction

Thank you for choosing the Summit Rifle, 22 LR Magpul Stock O.D. Green. This guide provides essential safety instructions to ensure your safe and enjoyable experience with your new rifle. It is important to follow these guidelines to minimize risks and ensure compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always treat the rifle as if it is loaded.
- Keep the rifle pointed in a safe direction at all times.
- Store the rifle securely and out of reach of children and unauthorized users.
- Use only the recommended ammunition for this rifle, which is .22 LR.
- Ensure you are in a safe environment when handling or using the rifle.
- Wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure a clear line of sight before firing.
- Do not modify the rifle or use any accessories that are not approved by the manufacturer.

Specific Safety Precautions for Use

- Ensure the safety mechanism is engaged when not in use.
- Before loading, visually inspect the chamber and magazine to confirm they are empty.
- Load the rifle only when you are ready to shoot.
- Do not place your finger on the trigger until you are ready to fire.
- Be cautious of the muzzle when loading, unloading, or handling the rifle.
- Avoid shooting in adverse weather conditions that may affect visibility or safety.
- If a misfire occurs, wait 30 seconds before attempting to clear the chamber.
- Always follow local laws and regulations regarding firearm use and ownership.

Instructions for Installation and Usage

1. Unboxing and Inspection

- Carefully remove the rifle from its packaging.
- Inspect the rifle for any signs of damage or defects. Do not use if damaged.

2. Mounting the Scope (if applicable)

- Attach the scope to the integral Picatinny Rail using the provided mounting hardware.
- Ensure the scope is securely fastened and properly aligned.

3. Loading the Rifle

- Ensure the rifle is pointed in a safe direction.
- Open the bolt and insert the magazine into the magazine well.
- Load .22 LR cartridges into the magazine as per the manufacturer's instructions.
- Close the bolt to chamber a round.

4. Firing the Rifle

- Assume a stable shooting position.

- Engage the safety mechanism and prepare to fire.
- Aim at the target and ensure a clear line of sight.
- Disengage the safety mechanism and gently squeeze the trigger to fire.

5. Unloading the Rifle

- Point the rifle in a safe direction.
- Open the bolt to eject any chambered round.
- Remove the magazine and inspect the chamber to ensure it is empty.

6. Cleaning and Maintenance

- Regularly clean the rifle following the manufacturer's guidelines.
- Use appropriate cleaning supplies designed for firearms.
- Store the rifle in a dry and secure location when not in use.

Disposal Instructions

- Follow local regulations for the disposal of firearms and ammunition.
- If the rifle is no longer usable, contact a licensed firearms dealer for proper disposal.
- Do not discard the rifle in regular waste.

Contact Information for Further Support

For any inquiries regarding safety or product information, please reach out to your local authorized dealer or manufacturer's representative. Ensure you have the product details ready for assistance.

By following these safety guidelines, you can ensure a safer experience with your Summit Rifle, 22 LR Magpul Stock O.D. Green. Always prioritize safety and responsible handling practices. Thank you for your attention to these important instructions.