

TG2000 Rapid Release

The TG2000 Rapid Release allows your customers to change magazines quickly while maintaining their grip on their rifle.



This is done by utilizing two paddle release buttons that extend downward from the main magazine release. Either of these paddles can be removed, using the included hex key, or both can be kept on for ambidexterity.

Our TG2000 Rapid Release is only compatible with our Volquartsen TG2000 and TGS (Summit) Trigger Group.

Attributes

- Name: TG2000 Rapid Release
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231466
- Mfr. No.: VF10RR
- Make: Ruger
- Model: 10/22, TG2000, Competition Bolt
- UPC: 840300701142

Table of Contents

- [Startpage](#)
- [Deutsch: TG2000 Rapid Release Sicherheitshinweise](#)
- [English: TG2000 Rapid Release Safety Instruction Guide](#)

TG2000 Rapid Release Sicherheitshinweise

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des TG2000 Rapid Release von VOLQUARTSEN. Dieses Produkt wurde entwickelt, um Ihnen einen schnellen und einfachen Wechsel von Magazinen zu ermöglichen, während Sie Ihr Gewehr sicher im Griff haben. Um eine sichere Verwendung zu gewährleisten, sind die folgenden Sicherheitshinweise und Anweisungen zu beachten.

Allgemeine Sicherheitsrichtlinien

- Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie das Produkt verwenden.
- Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern und schutzbedürftigen Personen.
- Überprüfen Sie regelmäßig das Produkt auf Beschädigungen oder Abnutzungserscheinungen.
- Melden Sie unsichere Produkte oder Unfälle an die zuständigen Behörden.
- Informieren Sie sich über Rückrufaktualisierungen auf der EU Safety GatePlattform.

Besondere Sicherheitsvorkehrungen bei der Verwendung

- Stellen Sie sicher, dass das Gewehr vor dem Wechseln des Magazins entladen ist.
- Verwenden Sie den TG2000 Rapid Release nur mit dem Volquartsen TG2000 und der TGS (Summit) Abzugsgruppe.
- Achten Sie darauf, dass sich keine Hindernisse in der Nähe des Magazins befinden, während Sie die PaddleReleaseTasten betätigen.
- Betätigen Sie die ReleaseTasten vorsichtig, um Verletzungen zu vermeiden.
- Verwenden Sie den beiliegenden Sechskantschlüssel nur für den vorgesehenen Zweck, um die PaddleReleaseTasten zu montieren oder abzunehmen.

Anweisungen für Installation und Nutzung

Installation

1. **Überprüfen Sie das Produkt:** Stellen Sie sicher, dass alle Teile vorhanden und unbeschädigt sind.
2. **Montage der PaddleReleaseTasten:**
 - Verwenden Sie den Sechskantschlüssel, um eine oder beide PaddleReleaseTasten an der vorgesehenen Stelle zu befestigen.
 - Achten Sie darauf, dass die Tasten fest sitzen, um ein versehentliches Lösen zu vermeiden.

Nutzung

1. **Magazinwechsel:**
 - Halten Sie das Gewehr sicher im Griff.
 - Drücken Sie die PaddleReleaseTasten nach unten, um das Magazin zu lösen.
 - Entfernen Sie das leere Magazin und setzen Sie das neue Magazin ein.
 - Stellen Sie sicher, dass das neue Magazin richtig eingesetzt ist, bevor Sie mit dem Schießen fortfahren.

Entsorgungsanweisungen

- Entsorgen Sie das Produkt und alle Verpackungsmaterialien gemäß den örtlichen Vorschriften für die Abfallentsorgung.
- Achten Sie darauf, dass keine Teile des Produkts in die Umwelt gelangen.

Kontaktinformationen für weitere Unterstützung

Für weitere Informationen oder Unterstützung bei Sicherheitsanfragen wenden Sie sich bitte an den Kundendienst des Herstellers.

TG2000 Rapid Release Safety Instruction Guide

Introduction

Thank you for choosing the TG2000 Rapid Release. This product is designed to enhance your shooting experience by allowing quick magazine changes while maintaining a firm grip on your rifle. It is important to follow safety guidelines to ensure safe usage of this product.

General Safety Guidelines

- Ensure that all firearms and accessories are stored safely and securely, out of reach of children and unauthorized users.
- Always treat every firearm as if it is loaded.
- Familiarize yourself with the local laws and regulations regarding firearm usage and accessories.
- Use the TG2000 Rapid Release only with compatible models: Volquartsen TG2000 and TGS (Summit) Trigger Group.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Only use the TG2000 Rapid Release in a safe and controlled environment.
- Ensure that the firearm is pointed in a safe direction at all times when changing magazines.
- Avoid using the product in wet or damp conditions to prevent slippage or malfunction.
- Keep fingers away from the trigger and the firearm's action during magazine changes.
- Be cautious when removing or attaching the paddle release buttons; ensure that the firearm is unloaded during this process.
- If you experience difficulty with the product, cease use immediately and consult a qualified professional.

Instructions for Installation and Usage

Installation

1. **Gather Required Tools:** You will need the included hex key for installation.
2. **Prepare the Firearm:** Ensure that your firearm is unloaded and pointed in a safe direction.
3. **Attach the Paddle Release Buttons:**
 - Locate the main magazine release on your Volquartsen TG2000 or TGS Trigger Group.
 - Align the paddle release buttons with the designated slots on the magazine release.
 - Secure the buttons by tightening them with the hex key. Ensure they are firmly in place.

Usage

1. **Changing Magazines:**
 - Grip the rifle firmly with one hand.
 - Use your other hand to press either of the paddle release buttons to release the magazine.
 - Quickly replace the magazine while maintaining your grip on the rifle.
 - Ensure that the new magazine is seated properly before resuming use.
2. **Removing Paddle Release Buttons:**
 - If you prefer to use only one paddle or none, use the hex key to loosen and remove the desired paddle.
 - Store any removed paddles in a safe place for future use.

Disposal Instructions

- Dispose of the TG2000 Rapid Release in accordance with local regulations regarding electronic waste and firearm accessories.
- Do not dispose of the product in regular household waste.
- If you are unsure about disposal methods, contact your local waste management authority for guidance.

Contact Information for Further Support

For any questions or concerns regarding the TG2000 Rapid Release, please reach out to the manufacturer's customer support team or consult the product's official website.

By following these safety instructions, you can ensure a safe and enjoyable experience with your TG2000 Rapid Release. Thank you for prioritizing safety.