

Magazine for Target 22 Style Scorpion Pistols - 10-Round - Volquartsen

Volquartsen magazine for Ruger MKIII and MK IV

This magazine fits our Target 22 style Scorpion pistols and target frames as well as Ruger MKIII and MK IV pistols. It is not compatible with Ruger 22/45 pistols or Volquartsen 1911-style pistols.



Features:

- **Compatibility:** Designed for Ruger MKIII and MK IV pistols.
- **Capacity:** Original 10-round Ruger magazine.
- **Manufacture:** Made by Ruger.
- **Pre-assembled:** Includes the Volquartsen Magazine Follower Button for Ruger pistols and the Surefeed Magazine Follower Spring for Ruger MKII, MKIII and MK IV.
- **Note:** Not compatible with Ruger 22/45 pistols or Volquartsen 1911-style pistols.

Attributes

- Name: Magazine for Target 22 Style Scorpion Pistols - 10-Round - Volquartsen
- Manufacturer: VOLQUARTSEN
- Product no.: BRD231522
- Mfr. No.: VC3FM
- Capacity: 10-Round
- Make: Volquartsen
- Model: Scorpion
- Delivery weight: 0.3kg
- UPC: 810162016364

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das Volquartsen Magazin für Target 22 Style Scorpion Pistolen](#)
- [English: Safety Instruction Guide for Volquartsen Magazine for Target 22 Style Scorpion Pistols](#)

Sicherheitshinweise für das Volquartsen Magazin für Target 22 Style Scorpion Pistolen

Einführung

Herzlichen Glückwunsch zu Ihrem Kauf des Volquartsen Magazins für Target 22 Style Scorpion Pistolen. Dieses Produkt wurde entwickelt, um die Leistung Ihrer Ruger MKIII und MK IV Pistolen zu verbessern. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere und effektive Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt für Ihren spezifischen Pistolenmodelltyp geeignet ist.
- Verwenden Sie das Magazin nur mit Ruger MKIII und MK IV Pistolen. Es ist nicht kompatibel mit Ruger 22/45 Pistolen oder Volquartsen 1911Style Pistolen.
- Halten Sie das Magazin und die Pistole außerhalb der Reichweite von Kindern und anderen unbefugten Personen.
- Überprüfen Sie regelmäßig auf mögliche Schäden am Magazin und an der Pistole.
- Melden Sie unsichere Produkte oder Unfälle den zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Verwendung

- Verwenden Sie das Magazin nur in einer sicheren Umgebung, in der das Schießen erlaubt ist.
- Tragen Sie immer geeignete Schutzausrüstung, einschließlich Schutzbrille und Gehörschutz.
- Stellen Sie sicher, dass die Waffe vor dem Einsetzen des Magazins entladen ist.
- Überprüfen Sie das Magazin auf Fremdkörper oder Beschädigungen, bevor Sie es verwenden.
- Laden Sie das Magazin gemäß den Anweisungen des Herstellers und achten Sie darauf, dass die Munition korrekt eingesetzt wird.

Anweisungen zur Installation und Nutzung

• Installation des Magazins:

1. Stellen Sie sicher, dass die Waffe entladen ist.
2. Nehmen Sie das Magazin aus der Verpackung.
3. Setzen Sie das Magazin vorsichtig in die Waffe ein, bis Sie ein Klicken hören.
4. Überprüfen Sie, ob das Magazin sicher sitzt.

• Nutzung des Magazins:

1. Laden Sie das Magazin mit der entsprechenden Munition.
2. Achten Sie darauf, dass der Volquartsen Magazine Follower Button korrekt installiert ist.
3. Verwenden Sie die Surefeed Magazine Follower Spring für Ruger MKII, MKIII und MK IV.
4. Führen Sie regelmäßig Wartungsarbeiten durch, um die Funktionalität des Magazins sicherzustellen.

Entsorgungsanweisungen

- Entsorgen Sie das Magazin gemäß den örtlichen Vorschriften für die Entsorgung von Waffen und Munitionszubehör.
- Stellen Sie sicher, dass das Magazin nicht mehr verwendet werden kann, bevor Sie es entsorgen.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Unterstützung zu diesem Produkt wenden Sie sich bitte an den Kundendienst oder den Händler, bei dem Sie das Produkt erworben haben. Es ist wichtig, dass alle Anfragen zu Sicherheitsfragen oder Problemen über die entsprechenden Kanäle erfolgen.

Bitte beachten Sie die neuesten Sicherheitsupdates und Rückrufinformationen auf der EU Safety Gate Plattform, um sicherzustellen, dass Ihr Produkt sicher ist.

Safety Instruction Guide for Volquartsen Magazine for Target 22 Style Scorpion Pistols

Introduction

Thank you for choosing the Volquartsen magazine for your Target 22 style Scorpion pistols. This guide provides essential safety instructions to ensure the safe and proper use of your magazine. Please read this guide carefully before using the product.

General Safety Guidelines

To ensure your safety and the safety of others, please adhere to the following guidelines:

- Always treat every firearm as if it is loaded.
- Keep the magazine and firearm out of the reach of children and unauthorized users.
- Inspect the magazine before use to ensure it is free of damage or defects.
- Use only compatible firearms as specified in the product description.
- Follow all local laws and regulations regarding firearm and magazine use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

When using the Volquartsen magazine for Target 22 style Scorpion pistols, please observe the following precautions:

- Ensure that the magazine is fully inserted into the firearm before attempting to fire.
- Avoid overloading the magazine beyond its 10round capacity.
- Do not attempt to modify or disassemble the magazine.
- Always use the magazine in a safe and controlled environment.
- In case of a misfire or malfunction, follow the manufacturer's guidelines for clearing the firearm safely.

Instructions for Installation and Usage

To ensure proper installation and usage of the magazine, follow these steps:

1. Installation:

- Ensure the firearm is pointed in a safe direction and that it is unloaded.
- Align the magazine with the magazine well on the firearm.
- Push the magazine firmly into the magazine well until it clicks into place.

2. Loading the Magazine:

- Hold the magazine with the follower facing up.
- Load one round at a time into the magazine, ensuring each round is seated properly.
- Do not exceed the 10round capacity of the magazine.

3. Using the Firearm:

- After loading the magazine, insert it into the firearm as described above.
- Follow the manufacturer's instructions for operating the firearm safely.
- Always ensure that the firearm is pointed in a safe direction when loading or unloading.

4. Unloading the Magazine:

- To unload the magazine, remove it from the firearm.
- Press the magazine release button and allow the magazine to drop free.
- Remove any remaining rounds from the magazine before storing.

Disposal Instructions

When the magazine reaches the end of its life or if it becomes damaged, dispose of it responsibly. Follow these guidelines:

- Do not dispose of the magazine in regular household waste.
- Contact your local waste management authority for proper disposal methods.
- Ensure that the magazine is rendered unusable before disposal to prevent misuse.

Contact Information for Further Support

For any questions or concerns regarding the Volquartsen magazine for Target 22 style Scorpion pistols, please refer to the manufacturer's contact information provided with your purchase.

Thank you for prioritizing safety and responsible use of your firearm accessories.