

Zwei Patronenhalter .223 - 9,3 x74R.

Two cartridge holder for rifle cartridges.

Made of high quality neoprene, Alpha Precision's cartridge holder provides a secure hold for .223 - 9.3 x74R caliber cartridges.



Because it is made of two layers of neoprene, the bottom stays firmly on the gun while the top layer, combined with a tight elastic band, tightly encloses the inserted cartridges.

Mounting:

The Two Cartridge Holder adheres to plastic, metal and grease-free wood.

Caution: It cannot be ruled out that the bonding MAY leave residue / discoloration on the gun.

For mounting, the surface must be free of grease and impurities as well as moisture.

Now remove the white protective film of the adhesive backing and press on several times at the desired position.

For a long life, please let it rest for approx. one hour.

Now the cartridge holder can be loaded with cartridge.

Scope of delivery:

1x two cartridge holder **WITHOUT** cartridges

Attributes

- Name: Zwei Patronenhalter .223 - 9,3 x74R.
- Manufacturer: ALPHA PRECISION
- Product no.: BRD611006
- Mfr. No.: 0028
- Caliber: .223 - 9,3 x74R.
- Color: Black
- Make: Alpha Precision
- Material: Neoprene
- Delivery weight: 0.1kg

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für den Zwei Patronenhalter .223 9,3 x74R](#)
- [English: Safety Instruction Guide for Zwei Patronenhalter .223 9,3 x74R](#)

Sicherheitshinweise für den Zwei Patronenhalter .223 9,3 x74R

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des Zwei Patronenhalters von Alpha Precision. Dieser Halter wurde entwickelt, um Ihnen einen sicheren Halt für Ihre Büchsenpatronen im Kaliber .223 9,3 x74R zu bieten. Bitte lesen Sie diese Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass der Zwei Patronenhalter nur für die vorgesehenen Kaliber verwendet wird.
- Überprüfen Sie regelmäßig den Zustand des Halters, um sicherzustellen, dass er keine sichtbaren Schäden aufweist.
- Verwenden Sie den Halter nicht, wenn er beschädigt ist oder Anzeichen von Abnutzung zeigt.
- Halten Sie den Halter und die Patronen außerhalb der Reichweite von Kindern.
- Befolgen Sie alle Anweisungen zur Montage und Nutzung, um Verletzungen oder Schäden zu vermeiden.

Spezifische Sicherheitsvorkehrungen für die Benutzung

- Achten Sie darauf, dass der Untergrund, auf dem der Halter montiert wird, frei von Fett, Verunreinigungen und Feuchtigkeit ist.
- Vermeiden Sie die Verwendung des Halters auf Oberflächen, die nicht für die Montage geeignet sind (z. B. unebene oder poröse Materialien).
- Verwenden Sie den Halter nur in Verbindung mit den vorgesehenen Patronen.
- Überprüfen Sie vor der Verwendung, ob der Halter sicher an der Waffe befestigt ist.

Anweisungen zur Installation und Nutzung

1. **Vorbereitung:** Stellen Sie sicher, dass die Oberfläche, auf der der Halter angebracht werden soll, sauber, trocken und fettfrei ist.
2. **Schutzfilm entfernen:** Ziehen Sie den weißen Schutzfilm des Kleberückens ab.
3. **Positionierung:** Platzieren Sie den Halter an der gewünschten Stelle auf der Waffe.
4. **Befestigung:** Drücken Sie den Halter mehrmals fest an, um sicherzustellen, dass er gut haftet.
5. **Ruhen lassen:** Lassen Sie den Halter für ca. eine Stunde ruhen, um die Klebeverbindung zu stärken.
6. **Patronen bestücken:** Nach der Ruhezeit können Sie den Halter mit den Patronen bestücken.

Entsorgungsanweisungen

- Entsorgen Sie den Zwei Patronenhalter gemäß den örtlichen Vorschriften für Kunststoffabfälle.
- Achten Sie darauf, dass der Halter nicht in den normalen Hausmüll gelangt, wenn er beschädigt ist.

Kontaktinformationen für weitere Unterstützung

Für Fragen oder Anliegen bezüglich der Sicherheit oder Nutzung des Produktes wenden Sie sich bitte an den Hersteller oder den Verkäufer, bei dem Sie das Produkt erworben haben.

Bitte beachten Sie, dass Sie unsicheres Verhalten und Produkte an die zuständigen Behörden melden sollten. Überprüfen Sie regelmäßig die Rückrufupdates auf der EU Safety GatePlattform.

Vielen Dank, dass Sie sich die Zeit genommen haben, diese Sicherheitshinweise zu lesen. Wir wünschen Ihnen viel Freude mit Ihrem Zwei Patronenhalter!

Safety Instruction Guide for Zwei Patronenhalter .223 9,3 x74R

Introduction

Thank you for choosing the Zwei Patronenhalter .223 9,3 x74R. This product is designed to securely hold rifle cartridges while ensuring safe and efficient use. Please read this safety instruction guide carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Ensure that you are aware of the product's intended use and limitations.
- Always handle firearms and ammunition responsibly and in accordance with local laws and regulations.
- Keep the cartridge holder out of reach of children and vulnerable individuals.
- Regularly inspect the cartridge holder for any signs of wear or damage before use.

Specific Safety Precautions for Use

- Do not use the cartridge holder if it shows signs of damage or wear.
- Ensure that the surface of the firearm is clean and free from grease or moisture before applying the holder.
- Avoid placing the cartridge holder on heated surfaces, as this may affect the adhesive and material integrity.
- Be cautious when removing the holder from the firearm, as it may leave residue or discoloration on the surface.
- Always check that the cartridges are properly secured within the holder before use.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and safe to handle.
- Clean the surface where the holder will be mounted, ensuring it is free of grease, dirt, and moisture.

2. Mounting the Cartridge Holder:

- Remove the white protective film from the adhesive backing of the cartridge holder.
- Position the holder at the desired location on the firearm.
- Press the holder firmly against the surface several times to ensure proper adhesion.
- Allow the holder to rest for approximately one hour before loading it with cartridges.

3. Loading Cartridges:

- Once the holder is securely mounted, gently insert the cartridges into the holder.
- Ensure that the top layer of neoprene and the elastic band tightly enclose the cartridges for a secure hold.

4. Usage:

- When using the firearm, ensure that the cartridge holder does not obstruct any operational parts of the firearm.
- Regularly check the holder during use to confirm that it remains securely attached and that the

cartridges are properly held.

Disposal Instructions

- Dispose of the cartridge holder in accordance with local waste disposal regulations.
- Do not dispose of the holder in fire, as it may release harmful substances.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Zwei Patronenhalter .223 9,3 x74R, please contact the manufacturer or your local retailer for assistance.

Remember to always prioritize safety and responsible usage when handling firearms and ammunition. Thank you for your attention to these guidelines, and enjoy using your Zwei Patronenhalter.