

Grip Insert - S&W - K Frame, L Frame - Square Butt

This model of grip shells is suitable for Smith&Wesson L- and K-frames with a square grip.



Attributes

- Name: Grip Insert - S&W - K Frame, L Frame - Square Butt
- Manufacturer: RANSOM
- Product no.: BRD612052
- Mfr. No.: 30-300-26-03
- Caliber: Multi
- Make: S&W
- Material: Polyurethane
- Model: K Frame, L Frame
- Delivery weight: 0.5kg

Table of Contents

- [Startpage](#)
- [Deutsch: Sicherheitshinweise für das RANSOM Grip Insert](#)
- [English: Grip Insert Safety Instruction Guide](#)

Sicherheitshinweise für das RANSOM Grip Insert

Einleitung

Herzlichen Glückwunsch zu Ihrem Kauf des RANSOM Grip Insert für S&W K Frame, L Frame! Dieses Produkt wurde entwickelt, um Ihnen eine bessere Handhabung Ihrer Kurzwaffe zu ermöglichen. Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch, um eine sichere Nutzung zu gewährleisten.

Allgemeine Sicherheitsrichtlinien

- Stellen Sie sicher, dass das Produkt gemäß den Anweisungen des Herstellers verwendet wird.
- Überprüfen Sie regelmäßig auf Beschädigungen oder Verschleiß.
- Halten Sie das Produkt außerhalb der Reichweite von Kindern.
- Informieren Sie sich über Rückrufaktionen auf der EU Safety Gate Plattform.
- Melden Sie unsichere Produkte oder Unfälle an die zuständigen Behörden.

Spezifische Sicherheitsvorkehrungen für die Nutzung

- Verwenden Sie das RANSOM Grip Insert nur für die vorgesehenen Modelle (S&W K Frame, L Frame).
- Achten Sie darauf, dass das Insert korrekt installiert ist, um ein Abrutschen oder Verrutschen während der Nutzung zu verhindern.
- Verwenden Sie das Produkt niemals, wenn es beschädigt ist.
- Verwenden Sie das Insert nicht unter dem Einfluss von Alkohol oder Drogen.
- Tragen Sie geeignete Schutzausrüstung, wenn Sie mit Ihrer Kurzwaffe schießen.

Anleitung zur Installation und Nutzung

1. Vorbereitung:

- Stellen Sie sicher, dass die Waffe entladen ist, bevor Sie das Grip Insert installieren.
- Reinigen Sie den Griffbereich der Waffe gründlich.

2. Installation:

- Entfernen Sie den vorhandenen Griff, falls nötig.
- Positionieren Sie das RANSOM Grip Insert auf dem Griff.
- Befestigen Sie das Insert gemäß den Anweisungen des Herstellers.
- Überprüfen Sie, ob das Insert fest sitzt und keine Bewegungen zulässt.

3. Nutzung:

- Halten Sie die Waffe mit beiden Händen und achten Sie darauf, dass der Griff sicher in Ihrer Hand liegt.
- Üben Sie regelmäßig, um ein Gefühl für das Insert zu bekommen und Ihre Technik zu verbessern.

Entsorgungsanweisungen

- Entsorgen Sie das RANSOM Grip Insert gemäß den örtlichen Vorschriften für Kunststoffabfälle.
- Informieren Sie sich über Recyclingmöglichkeiten in Ihrer Nähe.

Kontaktinformationen für weitere Unterstützung

Bei Fragen oder Anliegen zu Ihrem RANSOM Grip Insert wenden Sie sich bitte an den Hersteller oder den Händler, bei dem Sie das Produkt gekauft haben. Sie stehen Ihnen für weitere Informationen und Unterstützung

zur Verfügung.

Bitte beachten Sie, dass die Sicherheit und der verantwortungsvolle Umgang mit Ihrer Kurzwaffe oberste Priorität haben. Lesen Sie alle Anweisungen sorgfältig durch und befolgen Sie die Sicherheitsrichtlinien, um ein sicheres Schießerlebnis zu gewährleisten.

Grip Insert Safety Instruction Guide

Introduction

Thank you for choosing the Grip Insert for your Smith & Wesson K Frame and L Frame with a square butt. This guide provides important safety instructions and guidelines to ensure safe and effective use of the product. Please read this document carefully before installation and use.

General Safety Guidelines

- Ensure that the Grip Insert is compatible with your specific firearm model before use.
- Always handle firearms with care and follow standard safety practices.
- Keep the Grip Insert out of reach of children and unauthorized users.
- Regularly inspect the Grip Insert for any signs of wear or damage.
- If the Grip Insert becomes damaged, discontinue use immediately and replace it.
- Report any unsafe product experiences or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Compatibility Check:** Verify that the Grip Insert is designed for Smith & Wesson K Frame and L Frame firearms.
- **Material Safety:** The Grip Insert is made from polyurethane. Ensure no allergic reactions occur during handling.
- **Installation:** Follow the installation instructions closely to prevent improper use.
- **Usage:** Always ensure the firearm is unloaded when installing or adjusting the Grip Insert.
- **Storage:** Store the Grip Insert in a cool, dry place away from direct sunlight.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is completely unloaded.
- Gather necessary tools (if applicable) for installation.

2. Installation:

- Align the Grip Insert with the grip of the firearm.
- Press firmly to secure the Grip Insert in place.
- Ensure that the Grip Insert fits snugly without any gaps.

3. Usage:

- Once installed, check the stability of the Grip Insert before using the firearm.
- Practice safe handling techniques when using your firearm with the Grip Insert installed.

4. PostInstallation Check:

- After installation, recheck the grip to ensure it is secure.
- Perform a function check of the firearm to ensure proper operation.

Disposal Instructions

- Dispose of the Grip Insert in accordance with local regulations.
- Do not dispose of the Grip Insert in regular household waste.

- Consider recycling options if available in your area.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Grip Insert, please refer to the contact information provided by the manufacturer or retailer where the product was purchased.

Thank you for your attention to these safety instructions. Your safety and the safe use of your firearm are of utmost importance.