

Bullet Feeder Die Assembly Only (.308)

Maximize your press output. Increase the speed and efficiency of your reloading process with the Armanov Bullet Feeder Die. Precision-engineered from heavy-duty, zinc-plated steel, this die ensures that bullets feed flawlessly—one by one—directly into your press station without skipping or jamming.



Attributes

- Name: Bullet Feeder Die Assembly Only (.308)
- Manufacturer: ARMANOV
- Product no.: EU2018273
- Mfr. No.: BFDIE308
- Colour: Silver
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Bullet Feeder Die Assembly Only \(.308\)](#)

Safety Instruction Guide for Bullet Feeder Die Assembly Only (.308)

Introduction

Thank you for choosing the Bullet Feeder Die Assembly Only (.308) by Armanov. This guide provides essential safety instructions and guidelines for the proper use of this product. It is crucial to follow these instructions to ensure safe operation and to maximize the efficiency of your reloading process.

General Safety Guidelines

- Always use the Bullet Feeder Die in accordance with the manufacturer's instructions.
- Ensure that the product is compatible with your reloading press before use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Bullet Feeder Die for any signs of wear or damage before each use.
- Do not use the product if it is damaged or malfunctioning.
- Report any unsafe product experiences or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Risk of injury from moving parts during operation.
- Potential for jamming or misfeeding of bullets if not used properly.
- Risk of damage to the reloading press if the die is not installed correctly.

- **Avoiding Hazards:**

- Always ensure that the press is turned off and unplugged during installation or maintenance.
- Use the die only with the recommended caliber (.308) to prevent malfunction.
- Do not attempt to modify or disassemble the Bullet Feeder Die.
- Wear safety glasses and appropriate protective gear while reloading.
- Keep your workspace clean and organized to prevent accidents.

- **AgeSpecific Warnings:**

- This product is intended for use by individuals who are 18 years of age or older.
- Ensure that all users are trained in the safe handling of reloading equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure your reloading press is turned off and unplugged.
- Locate the appropriate mounting point on your press for the Bullet Feeder Die.
- Securely attach the Bullet Feeder Die to the press according to the manufacturer's specifications.
- Doublecheck that the die is firmly in place before proceeding.

2. Usage:

- Load the bullets into the feeder as per the manufacturer's instructions.
- Turn on the reloading press and monitor the feeding process closely.

- If a jam occurs, immediately stop the press and clear the obstruction before resuming.
- Regularly check the alignment of the die and the press during operation.

3. Maintenance:

- Clean the Bullet Feeder Die regularly to prevent buildup of debris.
- Lubricate moving parts as recommended by the manufacturer.
- Store the Bullet Feeder Die in a dry place when not in use.

Disposal Instructions

- Dispose of the Bullet Feeder Die in accordance with local regulations.
- Do not dispose of the product in household waste.
- If the product is no longer usable, consider recycling parts where applicable.

Contact Information for Further Support

For any questions or concerns regarding the Bullet Feeder Die Assembly Only (.308), please refer to the manufacturer's website or customer support resources for assistance.

Thank you for your attention to these safety instructions. Proper use and maintenance of the Bullet Feeder Die will enhance your reloading experience while ensuring safety.